



# Installation, Operation, and Maintenance Manual



Manual prepared specifically for:

**DESERT VIEW POWER LLC  
GREENLEAF POWER  
HYDRATED LIME DSI  
SYSTEM**

**MECCA, CA**

Purchase Order Numbers:  
Nol-Tec Job Information:  
Contract Numbers: 4723  
Job Numbers: 9222A

**VOLUME A  
OVERALL SYSTEM  
INFORMATION**



Manual prepared specifically for:

**DESERT VIEW POWER LLC  
GREENLEAF POWER  
HYDRATED LIME DSI  
SYSTEM**

**MECCA, CA**

Purchase Order Numbers:  
Nol-Tec Job Information:  
Contract Numbers: 4723  
Job Numbers: 9222A

**MATERIAL HANDLING SYSTEMS  
PROJECT MANAGER**

**Tim Kautz, Ext. 222**  
TIMKAUTZ@NOL-TEC.COM

**MATERIAL HANDLING SYSTEMS  
MECHANICAL ENGINEER**

**Jeff Wilkins, Ext. 281**  
JEFFWILKINS@NOL-TEC.COM

**MATERIAL HANDLING SYSTEMS  
ELECTRICAL ENGINEER**

**Jason Brown, Ext. 278**  
JASONBROWN@NOL-TEC.COM

**SPARE PARTS COORDINATOR**

**Dennis Iverson, Ext. 243**  
DENNISIVERSION@NOL-TEC.COM

**Operation & Maintenance Manual**  
*Desert View Power LLC, Greenleaf Power*  
*Hydrated Lime DSI System*  
MECCA, CA  
Nol-Tec Contract Numbers: 4723  
Nol-Tec Systems Site Numbers: 9222A

## **IOM Manual History Log**

---

<b>Status (Initial Release or Change)</b>	<b>Revision Number</b>	<b>Date Released</b>	<b>Section/Sub-Section Changed</b>
Initial Release	0	1/29/16	

**Operation & Maintenance Manual**  
*Desert View Power LLC, Greenleaf Power*  
*Hydrated Lime DSI System*  
MECCA, CA  
Nol-Tec Contract Numbers: 4723  
Nol-Tec Systems Site Numbers: 9222A

## **Table of Contents**

**Revision Date**

---

### **Volume A: Overall System Information**

#### **Section A1. Main Single Level Bill of Materials**

A1.1 Bill of Material, Site 9222 System A, Hydrated Lime DSI System – 67018

#### **Section A2. Mechanical Drawings**

A2.1 Drawings, Mechanical Installation Arrangement – 9222A-2

A2.2 Drawings, Piping & Instrumentation Diagrams – 9222A-4

#### **Section A3. Electrical Drawings**

A3.1 Drawings, Electrical Installation Arrangement – 9222A-7

#### **Section A4. Spare Parts List**

A4.1 Recommended Spare Parts List

#### **Section A5. Engineering Information & Lists**

A5.1 Operational Description

A5.2 Air Settings Sheet

#### **Section A6. Nol-Tec Systems, Inc. Standard Manuals**

A6.1 System Installation Manual

A6.2 Instructions for Storage of Nol-Tec Equipment

A6.3 Maintenance Schedule

A6.4 Pneumatic Conveying System Operating & Trouble Shooting Manual

**Operation & Maintenance Manual**  
*Desert View Power LLC, Greenleaf Power*  
*Hydrated Lime DSI System*  
MECCA, CA  
Nol-Tec Contract Numbers: 4723  
Nol-Tec Systems Site Numbers: 9222A

**Section A1. Main Single Level Bill of Materials**

---

**Revision Date**

A1.1 Bill of Material, Site 9222 System A, Hydrated Lime DSI System – 67018



425 Apollo Drive  
Lino Lakes, MN 55014  
Phone: (651) 780-8600  
Fax: (651) 780-4400

## BILL OF MATERIAL

Catalog Number: 67018

SITE 9222 SYSTEM A  
DESERT VIEW POWER - GREENLEAF POWER  
PO #XXXXXXXXXX  
HYDRATED LIME DSI SYSTEM

Item #	Part #	Qty	UOM	Drawing	Description	Schedule B
A	001	67328	1 EA		PAINT SPECIFICATION #9222 DESERT VIEW POWER NOL-TEC 9222A-10	
A	010	67031	1 EA		FRAME, LOWER, DAY BIN, ASEM NOL-TEC 9222A-14	M
A	011	67027	1 EA		FRAME, UPPER, DAY BIN, 250 CU. FT. HOPPER, ASEM NOL-TEC 9222A-15	M
A	012	67333	1 EA		DUST COLLECTOR, 60NT25, MS, ASEM WITH EXHAUSTER MOUNTING NOL-TEC 238-25-60-265-24-2-ASEM	M
A	013	67028	1 EA		BLOWER PACKAGE, PRESSURE, 20 HP, 200 SCFM @ 10 PSIG, 3/60/460V, TEFC NOL-TEC (HARDY) SOUND ENCLOSURE 9222A-21 (HPP-MD5003-20HP-2.5-4)	
A	014	67026	2 EA		BLOWER PACKAGE, PRESSURE, 20 HP, 200 SCFM @ 10 PSIG, 3/60/460V, TEFC NOL-TEC (HARDY) SOUND ENCLOSURE 9222A-20 (HPP-MD5003-20HP-2.5-3)	
A	015	67590	2 EA		HEAT EXCHANGER, AIR COOLED, 1HP, 3" IN & OUT, INSTRUMENT COUPLING, 279 F TO 132 FNOL-TEC (XCHANGER, INC) 9222A-61 (MODEL AA-250, RH)	
A	016	67599	1 EA		LADDER, DAY BIN ACCESS, 24'-7" TALL, MS, BOLTED CONNECTION NOL-TEC (BELGRADE) 9222A-63	
A	017	67664	1 EA		TRAILER, PNEUMATIC DRY BULK TANK, 1600 CU FT, ASEM NOL-TEC 9222A-62	M
A	018	67613	1 EA		LIGHTNING PROTECTION, ASEM, DAY BIN, NOL-TEC 9222A	M
A	019	67381	2 EA		CONNECTOR, FLEX 4 3/4" ID x 6 5/8" ID 5" LG RCN OUTER, W/ 5" LG .020 THK LINER NOL-TEC (w/ clamps)	

# BILL OF MATERIAL

Catalog Number: 67018

SITE 9222 SYSTEM A  
DESERT VIEW POWER - GREENLEAF POWER  
PO #XXXXXXXXXX  
HYDRATED LIME DSI SYSTEM

Item #	Part #	Qty	UOM	Drawing	Description	Schedule B	
A	020	67352	2 EA		9222A-49 ADAPTER, FLGD, 6" DIA. X 2-1/2" LG, MS WITH 7GA. PLATE RING FLANGE NOL-TEC		
A	021	61500	2 EA		9222A-45 SCALE, BENCH, 1,000#, 18 X 24 x 5.25 SINGLE POINT, RL1260 LOAD CELL RICE LAKE 18620	8423.89.0000	
A	022	28974	3 EA		TRANSMITTER, PRESSURE, -15 TO +15 PSIG 4-20mA, 1/2 CONDUIT, 1/2" MNPT/1/4"FNPT ENDRESS-HAUSER PMC 131-A22F1V6N	9026.20.0000 US-2	
A	023	55864	5 EA		TRANSMITTER, TEMP, RTD, 1/2 NPT, 0-400 FPYROMATION 4" INSERT, 2-WIRE RBF185L482-S4C0408-SC-8HN31, T440-285U-S (0-400) F		
A	024	10151	29 EA		CLAMP, QUICK RELEASE, 301SS NOL-TEC LS104 (229-999)	8421.91.0080 MEX-2	
A	025	32533	25 EA		FILTER, CARTRIDGE, BTM RMVL, 30 SQ FT 36", SB SPUN BOND POLY, 42.6"OAL, TDC FILTER MFG (MAX TEMP 225F) 80000923 (N/T 388-41)	8421.99.0080 USA-3	
A	026	20515	1 EA		EXHAUSTER, PB14A, 1100 CFM, 3HP, 6" SP, 8" INLET, CCW BH, ARR4, 230/460V CINCINNATI FAN (W/DISCHRG GUARD) 287-97 PB-14A	8414.51.0010	
A	027	10433	5 FT		HOSE, FLEXAUST, 8" ID APACHE RFH-8	3917.39.0000-USA-1	
A	028	67409	6 EA		ENCLOSURE, FIELD DISCONNECT NOL-TEC		M
A	029	67375	1 EA		9222A-53 CONTROL ENCLOSURE, DC, 5-BANK, 24 VDC, NEMA 4X, W/TIMER BOARD, DIFF PRESS TRANS NOL-TEC		M
A	030	67420	1 EA		9222A-47 VALVE, BUTTERFLY, 5", SERIES 30, ASEM 118 TRIM, 92-ACT, MLS, MAC SGL SOL,24VDC NOL-TEC	8481.80.9035-USA-1	M
A	031	67431	2 EA		BF-5-30-118-92-MLS-MAC-SGL-24VDC-ASEM GRAVITY SPLITTER, ASEM 3" SCH 40 INLET,(4)1-1/2" SCH 40 OUTLETS NOL-TEC		M
A	032	17192	1 EA		9222A-56 ADAPTER, FLGD, 5" SCH 40 X 6" LG, MS		



# BILL OF MATERIAL

Catalog Number: 67018

SITE 9222 SYSTEM A

DESERT VIEW POWER - GREENLEAF POWER

PO #XXXXXXXXXX

HYDRATED LIME DSI SYSTEM

Item #	Part #	Qty	UOM	Drawing	Description	Schedule B
A	033	67372	1 EA		NOL-TEC 209-100-05-40-6.00-MS BRACKET, SUPPORT FOR 4" & 5" PIPE, MS, DAY BIN SUPPORT	
A	034	65249	8 EA		NOL-TEC 9222A-46 BEND, CROSS, 1-1/2" SCH 40, MS, FAB (2) ENDS CAPPED	
A	035	55168	1 EA		NOL-TEC 9131A-65 BEND, TEE, 4" SCH 40, MS PLAIN END	
A	036	63861	1 EA		NOL-TEC 418-3-4-40-MS BEND, TEE, 4" TO 6" SCH 40, MS, FAB (1) END CAP 90 DEG, 8" TO 6" REDUC FNG,NOL-TEC	
A	037	35784	10 EA		9179A-66 BEND, 3" SCH 40, 90 DEG, MS 24" CLR, 6" TAN & 6" TAN NOL-TEC	7307.92.9000 US
A	038	16685	6 EA	B-246-1	3-S40-90-24R-6T-6T-MS ELBOW, 5" SCH 40, 90 DEG, MS NOL-TEC	
A	039	62773	4 EA		246-1-5-40-17.00X17.00-MS ELBOW, 4" SCH 40, 90 DEG, MS 12" CLR, 6" & 6" TAN NOL-TEC (MORRIS) MODEL 392	
A	040	66059	8 EA		4-S40-90-12R-6T-6T-MS HOSE, 1-1/2" X 36", MATERIAL HANDLING 690SB, SCH 40 PLAIN ENDS, INT EXPANDED NOL-TEC	
A	041	67427	2 EA		9130A-60-36" HOSE, 3" X 7'-0", MATERIAL HANDLING, 690SB, PLAIN ENDS, INT EXPANDED NOL-TEC	
A	042	11845	100 FT		9222A-54 PIPE, 5" SCH 40, MS	
A	043	13810	100 FT		PIPE, 4" SCH 40, MS	7304.39.0000 USA-1
A	044	14372	300 FT		PIPE, 3" SCH 40, MS	7304.39.0000 USA -1
A	045	60316	80 FT		PIPE, 1-1/2" SCH 40, MS	
A	046	11355	15 EA		COUPLING, STYLE 99, 5" VICTAULIC 99-5-E	7307.11.0060
A	047	10211	15 EA		COUPLING, STYLE 99, 4" VICTAULIC 99-4-E	7307.11.0060-USA-1

# BILL OF MATERIAL

Catalog Number: 67018

SITE 9222 SYSTEM A  
DESERT VIEW POWER - GREENLEAF POWER  
PO #XXXXXXXXXX  
HYDRATED LIME DSI SYSTEM

Item #	Part #	Qty	UOM	Drawing	Description	Schedule B
A	048	10210	40 EA		COUPLING, STYLE 99, 3" VICTAULIC 99-3-E	7307.11.0060-USA-1
A	049	18741	32 EA		COUPLING, STYLE 99, 1-1/2" VICTAULIC 99-1-1/2-E	7307.11.0060-USA-1
A	050	65747	1 EA		U-BOLT, EXTND LENGTH, 4-9/16", 1/2"-13, HOT DIP GALVANIZED, FOR 4" PIPE, 4 NUTS MCMASTER CARR 8862T34	
A	051	65746	1 EA		U-BOLT, EXTND LENGTH, 5-5/8", 1/2"-13, HOT DIP GALVANIZED, FOR 5" PIPE, 4 NUTS MCMASTER CARR 8862T35	
A	052	16435	8 EA		BOLT, HEX HEAD, 3/4"-10 X 5", MS, PLT MINIMUM GRADE 5	7318.15.2000-TWN-2
A	053	11250	8 EA		BOLT, HEX HEAD, 3/4"-10 X 2-1/2", MS,PLT MINIMUM GRADE 5	7318.15.2000
A	054	11784	16 EA		NUT, HEX HEAD, 3/4"-10, MS, PLT	
A	055	11696	16 EA		LOCKWASHER, 3/4", MS, PLT	
A	056	61604	8 EA		BOLT, HEX HEAD, 1/2"-13 X 4", MS,PLT MINIMUM GRADE 5	
A	057	11235	12 EA		BOLT, HEX HEAD, 1/2"-13 X 1-1/2", MS,PLT MINIMUM GRADE 5	7318.15.2000-TWN-2
A	058	11778	28 EA		NUT, HEX HEAD, 1/2"-13, MS, PLT	
A	059	11692	20 EA		LOCKWASHER, 1/2", MS, PLT	
A	060	67430	1 EA		LIGHT, LED, 3K L, 120-277 VAC, 50/60HZ, 41W, 1-1/2" STANCHION STRAIGHT MOUNT, CROUSE & HINDS PVM 3L W P /UNV1	
A	061	67363	4 EA		LIGHT, LED, 3K L, 120-277 VAC, 50/60HZ, 41W, 1" WALL MOUNT, CROUSE & HINDS PVM 3L W 3TW /UNV1	
A	062	63472	1 EA		LIGHT, WALL MOUNT, 4" BOX, 100 W, W/ GLASS GLOBE & CAT GUARD 9-3/4" H X CRESCENT STONCO 7-1/4" W VWXL11GC	
A	063	67563	4 EA		NOZZLE, 1-1/2" LANCE INJECTOR, MS, (1) LANCE, 4" 150 LB MTG, 50" LG NOL-TEC 9222A-59	
A	064	67564	4 EA		NOZZLE, 1-1/2" LANCE INJECTOR, MS, (1) LANCE, 4" 150 LB MTG, 75" LG NOL-TEC 9222A-60	
A	065	45147	8 EA		FLANGE, 4", 150 LB, THREADED, MS	

# BILL OF MATERIAL

Catalog Number: 67018

SITE 9222 SYSTEM A

DESERT VIEW POWER - GREENLEAF POWER

PO #XXXXXXXXXX

HYDRATED LIME DSI SYSTEM

Item #	Part #	Qty	UOM	Drawing	Description	Schedule B
A	066	10602	8 EA		NIPPLE, 4" X 12", MS, GALV	
A	067	18198	8 EA		COUPLING, 4", MALL	
A	068	67715	1 EA		HOSE, 3" X 10'-0", MATERIAL HANDLING, 690SB, INT EXPANDED PLAIN END X INT EXPANDED FEMALE CAMLOCK NOL-TEC 9222A-71	
A	069	67598	1 EA		HOSE, 4" X 10'-0", MATERIAL HANDLING, 690SB, INT EXPANDED PLAIN END X INT EXPANDED FEMALE CAMLOCK NOL-TEC 9222A-64	
A	070	67602	1 EA		HOSE, 5" X 10'-0", MATERIAL HANDLING, 690SB, INT EXPANDED PLAIN END X INT EXPANDED FEMALE CAMLOCK NOL-TEC 9222A-65	
A	071	44836	1 EA	B-297-1	REDUCER, 4" TO 3" CONCENTRIC, MS NOL-TEC 297-1-3-40-4-40-PE-PE-MS	
A	072	67772	1 EA		AIR SUPPLY, TOP OF DAY BIN, ASEM, NOL-TEC 9222A-72	M
A	073	67985	3 EA		ENCLOSURE, FIELD DISCONNECT, 60 AMP, NOL-TEC 9222A-73	M
A	074	32357	2 EA		TEST WEIGHT, CALIBRATION, 50 LB RICE LAKE WEIGHING 12839	
A	075	51989	1 EA		SILICON RTV ADHESIVE, CLEAR, DOW CORNING 732, MCMASTER CARR 7587A3	
A	500	67626	1 EA		CONTROL ENCLOSURE (CP050) PIG REMOTE I/O PANEL NOL-TEC 9222A-7 (SHT. 50)	M


**Operation & Maintenance Manual**  
*Desert View Power LLC, Greenleaf Power*  
*Hydrated Lime DSI System*  
MECCA, CA  
Nol-Tec Contract Numbers: 4723  
Nol-Tec Systems Site Numbers: 9222A

## **Section A2. Mechanical Drawings**


---

**Revision Date**


- A2.1 Drawings, Mechanical Installation Arrangement – 9222A-2
- A2.2 Drawings, Piping & Instrumentation Diagrams – 9222A-4




PLAN VIEW




DAY BIN MOUNTING DETAIL  
SCALE = 2X

					AREA PLAN			 NOL-TEC SYSTEMS Lino Lakes, MN - USA www.nol-tec.com (651) 780-8600 ©2007
2	07JAN16	ADDED BRACKET	DAZ	JJW	MECHANICAL GENERAL ARRANGEMENT			
0	23NOV15	ISSUED FOR CONSTRUCTION	MJB	MJB	DRY SORBENT INJECTION SYSTEM			
A	11SEP15	ISSUED FOR APPROVAL	MJB	MJB	GREENLEAF POWER-DESERT VIEW			
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DRAWN BY M. BOSIO	DATE 04.Sep.15	CATALOG NO.	DRAWING NO.
					SCALE 3/8"=1'-0"	67018		9222A-2-003




DAY BIN ELEVATION				MECHANICAL GENERAL ARRANGEMENT		DRY SORBENT INJECTION SYSTEM		GREENLEAF POWER-DESERT VIEW	
0	23NOV15	ISSUED FOR CONSTRUCTION		MJB	MJB				
B	11SEP15	ISSUED FOR APPROVAL		MJB	MJB				
A	31AUG15	ISSUED FOR PRELIMINARY REVIEW		MJB	MJB	DRAWN BY M. BOSIO	DATE 12.Aug.15	CATALOG NO.	
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY M. BOSIO	SCALE 1"=1'-0"	67018	



**NOL-TEC**  
SYSTEMS  
Lino Lakes, MN • USA  
www.nol-tec.com (651) 780-8800


DRAWING NO.  
**9222A-2-004**





ELEVATION VIEW C  
SEE PLAN VIEW FOR  
CORRECT ORIENTATIONS 4


DAY BIN ELEVATION				MECHANICAL GENERAL ARRANGEMENT	
				DRY SORBENT INJECTION SYSTEM	
				GREENLEAF POWER-DESERT VIEW	
0	23NOV15	ISSUED FOR CONSTRUCTION	MJB	MJB	
B	11SEP15	ISSUED FOR APPROVAL	MJB	MJB	
A	31AUG15	ISSUED FOR PRELIMINARY REVIEW	MJB	MJB	
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY M. BOSIO

**NOL-TEC**  
SYSTEMS  
Lino Lakes, MN - USA  
www.nol-tec.com (651) 780-8800


DRAWING NO.  
**9222A-2-005**



CATALOG NO.  
67018

DATE 12.Aug.15  
SCALE 1"=1'-0"



DAY BIN SECTION PLAN VIEWS									
MECHANICAL GENERAL ARRANGEMENT									
DRY SORBENT INJECTION SYSTEM									
GREENLEAF POWER-DESERT VIEW									
0	23NOV15	ISSUED FOR CONSTRUCTION	MJB	MJB	DRAWN BY M. BOSIO				
B	11SEP15	ISSUED FOR APPROVAL	MJB	MJB	DATE 12.Aug.15				
A	31AUG15	ISSUED FOR PRELIMINARY REVIEW	MJB	MJB	SCALE 3/4"=1'-0"				
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY M. BOSIO	CATALOG NO. 67018			
									9222A-2-006








DAY BIN SECTION ELEVATIONS				MECHANICAL GENERAL ARRANGEMENT		NOL-TEC SYSTEMS	
				DRY SORBENT INJECTION SYSTEM		Lino Lakes, MN - USA	
				GREENLEAF POWER-DESERT VIEW		(651) 780-8800	
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY M. BOSIO	DATE 12.Aug.15	CATALOG NO. 67018
0	23NOV15	ISSUED FOR CONSTRUCTION	MJB	MJB			
B	11SEP15	ISSUED FOR APPROVAL	MJB	MJB			
A	31AUG15	ISSUED FOR PRELIMINARY REVIEW	MJB	MJB			



DRAWING NO. 9222A-2-007




GRAVITY SPLITTER FOOT PRINT




						INJECTION LOCATION ELEVATION			
						MECHANICAL GENERAL ARRANGEMENT			
						DRY SORBENT INJECTION SYSTEM			
						GREENLEAF POWER-DESERT VIEW			
0	23NOV15	ISSUED FOR CONSTRUCTION		MJB	MJB	DRAWN BY M. BOSIO		DATE 20.Nov.15	CATALOG NO.
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY M. BOSIO		SCALE 1"=1'-0"	67018




DRAWING NO.  
**9222A-2-008**








PIPING AND INSTRUMENT DIAGRAM				DRAWING NO.	
BLOWERS & HEAT EXCHANGERS				9222A-4-004	
DRY SORBENT INJECTION SYSTEM				NOL-TEC SYSTEMS	
GREENLEAF POWER-DESERT VIEW				Lino Lakes, MN - USA	
ISSUED FOR CONSTRUCTION				www.nol-tec.com	
ISSUED FOR APPROVAL				(651) 780-8600	
ISSUED FOR PRELIMINARY REVIEW				©2001	
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY M. BOSIO
0	19NOV15		MJB	MJB	DATE 19.Aug.15
B	24SEP15		MJB	MJB	SCALE NONE
A	31AUG15		MJB	MJB	CATALOG NO.







PIPING AND INSTRUMENT DIAGRAM				BIN DISCHARGE		NOL-TEC SYSTEMS	
BIN DISCHARGE				DRY SORBENT INJECTION SYSTEM		Lino Lakes, MN - USA	
GREENLEAF POWER-DESERT VIEW				DRAWN BY M. BOSIO		www.nol-tec.com (651) 780-8800	
ISSUED FOR CONSTRUCTION				DATE 19.Aug.15		CATALOG NO.	
ISSUED FOR APPROVAL				SCALE NONE		9222A-4-006	
ISSUED FOR PRELIMINARY REVIEW				DRAWN BY M. BOSIO		DESIGN BY M. BOSIO	
REVISION NOTE				REV		DATE	
O 19NOV15				MJB		MJB	
B 24SEP15				MJB		MJB	
A 31AUG15				MJB		MJB	



PIPING AND INSTRUMENT DIAGRAM				DRAWING NO.	
LIW FEEDERS 1 & 2				9222A-4-007	
DRY SORBENT INJECTION SYSTEM				CATALOG NO.	
GREENLEAF POWER-DESERT VIEW				SCALE NONE	
0	19NOV15	ISSUED FOR CONSTRUCTION	MJB MJB	DATE 19.Aug.15	CATALOG NO.
B	24SEP15	ISSUED FOR APPROVAL	MJB MJB	SCALE NONE	
A	31AUG15	ISSUED FOR PRELIMINARY REVIEW	MJB MJB	SCALE NONE	
REV	DATE	REVISION NOTE	DRAWN DESIGN DESIGN BY M. BOSIO	SCALE NONE	



**Operation & Maintenance Manual**  
*Desert View Power LLC, Greenleaf Power*  
*Hydrated Lime DSI System*  
MECCA, CA  
Nol-Tec Contract Numbers: 4723  
Nol-Tec Systems Site Numbers: 9222A

## **Section A3. Electrical Drawings**

---

**Revision Date**

A3.1 Drawings, Electrical Installation Arrangement – 9222A-7

# DESERT VIEW POWER

UNIT A &amp; B


MECCA, CA

DSI SYSTEM

NOL-TEC JOB 9222A


NOL-TEC SYSTEMS INC.

SYSTEM LETTERS COVERED UNDER THIS DRAWING PACKAGE		
SYSTEM LETTER	JOB NUMBER	DESCRIPTION OF THE SYSTEM
A	4723	DSISYSTEM


						CONTROL SYSTEM			Line Lakon, MN - USA (651) 780-0500 www.nol-tec.com ©2007
						COVER SHEET			
						DESERT VENT POWER UNIT A & B			
						MECCA, CA			
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NOLF	
									9222A-7-001



NOTES & SYMBOLS


 - EMERGENCY STOP PUSH BUTTON

 - SELECTOR SWITCH


 - NORMALLY OPEN PUSH BUTTON

 - NORMALLY CLOSED PUSH BUTTON

 - ALARM HORN


 - PILOT LIGHT  
A = AMBER    R = RED  
B = BLUE    W = WHITE  
C = CLEAR    Y = YELLOW  
G = GREEN

 - CIRCUIT BREAKER


 - FUSE

 - CONTROL RELAY / MOTOR STARTER

 - DUST FILTER TIMER BOARD


 - ZERO SPEED SWITCH


 - NORMALLY OPEN PROXIMITY SWITCH


 - SOLENOID


 - NORMALLY OPEN LIMIT SWITCH

 - NORMALLY CLOSED LIMIT SWITCH

 - NORMALLY OPEN PRESSURE SWITCH

 - NORMALLY CLOSED PRESSURE SWITCH

 - NORMALLY OPEN CONTACT SWITCH

 - NORMALLY CLOSED CONTACT SWITCH


 - NORMALLY OPEN TIMER CONTACT SWITCH  
DELAYED OPENING AFTER DE- ENERGIZED


 - NORMALLY CLOSED TIMER CONTACT SWITCH  
DELAYED OPENING AFTER DE- ENERGIZED

 - NORMALLY OPEN TIMER CONTACT SWITCH  
DELAYED OPENING AFTER ENERGIZED


 - NORMALLY CLOSED TIMER CONTACT SWITCH  
DELAYED OPENING AFTER ENERGIZED


 - NORMALLY OPEN TEMPERATURE SWITCH

 - NORMALLY CLOSED TEMPERATURE SWITCH

 - NORMALLY OPEN FLOW SWITCH

 - NORMALLY CLOSED FLOW SWITCH

 - GROUND

 - PLUG/CORD CONNECTION

A - AMP

CB - CIRCUIT BREAKER

CP - CONTROL PANEL

CR - CONTROL RELAY

ES - EMERGENCY STOP PUSH BUTTON

FLA - FULL LOAD AMPS

FS - FLOW SWITCH

FU - FUSE

GND - GROUND

HP - HORSEPOWER

JB - JUNCTION BOX

LSHH - LEVEL CONTROL EMERGENCY HIGH

LSH - LEVEL CONTROL HIGH

LSM - LEVEL CONTROL MID

LSL - LEVEL CONTROL LOW

MCR - MASTER CONTROL RELAY

MS - MOTOR STARTER

PB - PUSH BUTTON

PL - PILOT LIGHT

PSH - PRESSURE SWITCH HIGH

PSL - PRESSURE SWITCH LOW

PDS - PRESSURE DIFFERENTIAL SWITCH

PROX - PROXIMITY SWITCH

PT - PRESSURE TRANSDUCER

SS - SELECTOR SWITCH

TS - TEMPERATURE SWITCH

TMR - TIMER SWITCH

VFD - VARIABLE FREQUENCY DRIVE

XV - SOLENOID

ZSO - LIMIT SWITCH OPEN

ZSC - LIMIT SWITCH CLOSED

ZSS - ZERO SPEED SWITCH

WIRING NOTES:


- 1) ALL CONTROL WIRING TO BE RED 16 AWG MTW MINIMUM.
- 2) NEUTRAL TO BE WHITE 16 AWG MTW MINIMUM.
- 3) GROUND WIRING TO BE GREEN 16 AWG MTW MINIMUM.
- 4) DC WIRING TO BE BLUE 16 AWG MTW MINIMUM.
- 5) DC COMMON TO BE WHITE /w BLUE STRIPE 16 AWG MTW MINIMUM.
- 6) DUAL SOURCE VOLTAGES TO PANEL TO BE YELLOW 16 AWG MTW MINIMUM.
- 7) MOTOR WIRING TO BE BLACK 12 AWG MTW MINIMUM.
- 8) 2-WIRE ANALOG CABLING TO BE BELDEN 8761 OR EQUIVALENT.
- 9) 4-WIRE ANALOG CABLING TO BE BELDEN 8723 OR EQUIVALENT.
- 10) LOAD CELL SIGNAL CABLING TO BE 6 CONDUCTOR RICE LAKE SURVIVOR EL147HE OR EQUIVALENT.
- 11) C2 LOAD CELL SIGNAL CABLING TO BE 8 CONDUCTOR HARDY 6020-001/C2 CERTIFIED OR EQUIVALENT.
- 12) ALLEN BRADLEY CONTROL NET CABLE TO BE BELDEN 3092A COAX OR EQUIVALENT.
- 13) ETHERNET CABLING TO BE CAT 5e PLENUM RATED.
- 14) ALLEN BRADLEY DH+/RIO CABLING TO BE BELDEN 9463 (BLUE HOSE) OR EQUIVALENT.
- 15) SUPPLIED BY OTHERS.


TERMINAL NOTES:

- DENOTES TERMINALS IN CONTROL ENCLOSURE.
- DENOTES TERMINALS LOCATED IN REMOTE JUNCTION ENCLOSURE.
- DENOTES FIELD WIRING TO BE COMPLETED BY OTHERS.
- DENOTES WIRING COMPLETED BY NOL-TEC SYSTEMS INC.

XXX-XX-FIRST 3 DIGITS EQUALS THE PAGE & THE NEXT 2 DIGITS EQUALS THE ROW.

EXAMPLE: 015-06 WHERE 015 IS THE PAGE AND 06 IS THE ROW ON THAT PAGE.


AUX01506 COIL ID  
 COIL LOCATION

					CONTROL SYSTEM				
					NOTES & SYMBOLS				
					DESERT VIEW POWER UNIT A & B				
					MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.  DRAWING NO. <b>9222A-7-002</b>
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE	




DRAWING NUMBER	DESCRIPTION
9222A-7 - 001	CONTROL SYSTEM - COVER SHEET
9222A-7 - 002	CONTROL SYSTEM - NOTES & SYMBOLS
9222A-7 - 003	CONTROL SYSTEM - DRAWING INDEX
9222A-7 - 004	CONTROL SYSTEM - DRAWING INDEX
9222A-7 - 005	SPARE DRAWINGS (SHEETS 5-9)
9222A-7 - 006	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 007	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 008	SPARE DRAWING - PAGE NOT IN DRAWING SET
9222A-7 - 009	SPARE DRAWING - PAGE NOT IN DRAWING SET
9222A-7 - 010	MAIN CONTROL PANEL - ONE-LINE DIAGRAM
9222A-7 - 011	MAIN CONTROL PANEL - ONE-LINE DIAGRAM
9222A-7 - 012	SPARE DRAWINGS (SHEETS 12-14)
9222A-7 - 013	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 014	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 015	CONTROL SYSTEM - ETHERNET ARCHITECTURE
9222A-7 - 016	SPARE DRAWINGS (SHEETS 16-19)
9222A-7 - 017	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 018	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 019	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 020	CP020 MOTOR CONTROL PANEL - PANEL LAYOUT
9222A-7 - 021	CP020 MOTOR CONTROL PANEL - BACKPANEL LAYOUT
9222A-7 - 022	CP020 MOTOR CONTROL PANEL - BILL OF MATERIAL
9222A-7 - 023	CP020 MOTOR CONTROL PANEL - TERMINAL LAYOUT & LEGENDS
9222A-7 - 024	CP020 MOTOR CONTROL PANEL - 480VAC POWER DISTRIBUTION
9222A-7 - 025	CP020 MOTOR CONTROL PANEL - 480VAC POWER DISTRIBUTION
9222A-7 - 026	CP020 MOTOR CONTROL PANEL - 480VAC POWER DISTRIBUTION
9222A-7 - 027	SPARE DRAWING
9222A-7 - 028	CP020 MOTOR CONTROL PANEL - 120VAC & 24VDC POWER DISTRIBUTION
9222A-7 - 029	SPARE DRAWING
9222A-7 - 030	CP030 PLC CONTROL PANEL - PANEL LAYOUT
9222A-7 - 031	CP030 PLC CONTROL PANEL - BACKPANEL LAYOUT
9222A-7 - 032	CP030 PLC CONTROL PANEL - BILL OF MATERIAL
9222A-7 - 033	CP030 PLC CONTROL PANEL - TERMINAL LAYOUT & LEGENDS
9222A-7 - 034	CP030 PLC CONTROL PANEL - 24VDC POWER DISTRIBUTION
9222A-7 - 035	SPARE DRAWINGS (SHEETS 35-39)
9222A-7 - 036	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 037	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 038	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 039	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 040	CP030 PLC CONTROL PANEL - I/O WIRING DIAGRAM MODULE 0 & 1
9222A-7 - 041	CP030 PLC CONTROL PANEL - I/O WIRING DIAGRAM MODULE 2 & 3
9222A-7 - 042	CP030 PLC CONTROL PANEL - I/O WIRING DIAGRAM MODULE 4 & 5
9222A-7 - 043	CP030 PLC CONTROL PANEL - I/O WIRING DIAGRAM MODULE 6
9222A-7 - 044	CP030 PLC CONTROL PANEL - I/O WIRING DIAGRAM MODULE 7 & 8
9222A-7 - 045	CP030 PLC CONTROL PANEL - I/O WIRING DIAGRAM MODULE 9 & 10
9222A-7 - 046	CP030 PLC CONTROL PANEL - I/O WIRING DIAGRAM MODULE ETHERNET
9222A-7 - 047	SPARE DRAWINGS (SHEETS 47-49)
9222A-7 - 048	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 049	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 050	CP050 PIG REMOTE I/O PANEL - PANEL & BACKPANEL LAYOUT
9222A-7 - 051	CP050 PIG REMOTE I/O PANEL - BILL OF MATERIAL

DRAWING NUMBER	DESCRIPTION
9222A-7 - 052	CP050 PIG REMOTE I/O PANEL - TERMINAL LAYOUT & LEGENDS
9222A-7 - 053	CP050 PIG REMOTE I/O PANEL - 24VDC POWER SUPPLY
9222A-7 - 054	SPARE DRAWING (SHEET 54)
9222A-7 - 055	CP050 PIG REMOTE I/O PANEL - I/O WIRING DIAGRAM MODULE 0 & 1
9222A-7 - 056	CP050 PIG REMOTE I/O PANEL - I/O WIRING DIAGRAM MODULE 2 & 3
9222A-7 - 057	SPARE DRAWINGS (SHEETS 57-59)
9222A-7 - 058	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 059	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 060	INJECTION BLOWER 1 - FIELD DISCONNECT FD060
9222A-7 - 061	INJECTION BLOWER 2 - FIELD DISCONNECT FD061
9222A-7 - 062	PIG UNLOAD BLOWER - FIELD DISCONNECT FD062
9222A-7 - 063	LIW HOPPER 1FEEDER SCREW - FIELD DISCONNECT FD063
9222A-7 - 064	LIW HOPPER 2 FEEDER SCREW - FIELD DISCONNECT FD064
9222A-7 - 065	HEAT EXCHANGER 1 - FIELD DISCONNECT FD065
9222A-7 - 066	HEAT EXCHANGER 2 - FIELD DISCONNECT FD066
9222A-7 - 067	LIW HOPPER 1 AGITATOR - FIELD DISCONNECT FD067
9222A-7 - 068	LIW HOPPER 2 AGITATOR - FIELD DISCONNECT FD068
9222A-7 - 069	LIW HOPPER 1 VENT HOPPER AIRLOCK - FIELD DISCONNECT FD069
9222A-7 - 070	LIW HOPPER 2 VENT HOPPER AIRLOCK - FIELD DISCONNECT FD070
9222A-7 - 071	DUST FILTER EXHAUST BLOWER - FIELD DISCONNECT FD071
9222A-7 - 072	SPARE DRAWINGS (SHEETS 072-79)
9222A-7 - 073	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 074	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 075	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 076	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 077	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 078	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 079	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 080	PIG HOPPER - FIELD WIRING
9222A-7 - 081	BLOWER/HEAT EXCHANGERS - FIELD WIRING
9222A-7 - 082	DAY BIN - FIELD WIRING
9222A-7 - 083	DAY BIN - FIELD WIRING
9222A-7 - 084	DAY BIN LINE 1 - FIELD WIRING
9222A-7 - 085	DAY BIN LINE 2 - FIELD WIRING
9222A-7 - 086	SPARE DRAWINGS (SHEETS 086-94)
9222A-7 - 087	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 088	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 089	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 090	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 091	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 092	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 093	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 094	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 095	DAY BIN ELEVATION - FIELD WIRING
9222A-7 - 096	DAY BIN ELEVATION - FIELD WIRING
9222A-7 - 097	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 098	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 099	SPARE DRAWING - SHEET NOT IN DRAWING SET


						CONTROL SYSTEM			 <div><b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA www.nol-tec.com (651) 780-8600 #280</div>		
						DRAWING INDEX					
						DESERT VIEW POWER UNIT A & B					
						MECCA, CA					
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.15	CATALOG NO.	DRAWING NO. <b>9222A-7-003</b>
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE		

DRAWING NUMBER	DESCRIPTION
9222A-7 - 100	JB100 LIW HOPPER 1 DIFFERENTIAL J-BOX - PANEL & BACKPANEL LAYOUT
9222A-7 - 101	JB100 LIW HOPPER 1 DIFFERENTIAL J-BOX - BILL OF MATERIAL, TERMINAL LAYOUT & LEGEND
9222A-7 - 102	JB100 LIW HOPPER 1 DIFFERENTIAL J-BOX - WIRING DIAGRAM
9222A-7 - 103	SPARE DRAWINGS - (SHEETS 103-104)
9222A-7 - 104	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 105	JB105 LIW VENT HOPPER 1 DIFFERENTIAL J-BOX - PANEL & BACKPANEL LAYOUT
9222A-7 - 106	JB105 LIW VENT HOPPER 1 DIFFERENTIAL J-BOX - BILL OF MATERIAL, TERMINAL LAYOUT & LEGEND
9222A-7 - 107	JB105 LIW VENT HOPPER 1 DIFFERENTIAL J-BOX - WIRING DIAGRAM
9222A-7 - 108	SPARE DRAWINGS - (SHEETS 108-109)
9222A-7 - 109	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 110	JB110 LIW HOPPER 2 DIFFERENTIAL J-BOX - PANEL & BACKPANEL LAYOUT
9222A-7 - 111	JB110 LIW HOPPER 2 DIFFERENTIAL J-BOX - BILL OF MATERIAL, TERMINAL LAYOUT & LEGEND
9222A-7 - 112	JB110 LIW HOPPER 2 DIFFERENTIAL J-BOX - WIRING DIAGRAM
9222A-7 - 113	SPARE DRAWINGS - (SHEETS 113-114)
9222A-7 - 114	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 115	JB115 LIW VENT HOPPER 2 DIFFERENTIAL J-BOX - PANEL & BACKPANEL LAYOUT
9222A-7 - 116	JB115 LIW VENT HOPPER 2 DIFFERENTIAL J-BOX - BILL OF MATERIAL, TERMINAL LAYOUT & LEGEND
9222A-7 - 117	JB115 LIW VENT HOPPER 2 DIFFERENTIAL J-BOX - WIRING DIAGRAM
9222A-7 - 118	SPARE DRAWINGS - (SHEETS 118-119)
9222A-7 - 119	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 120	JB120 SILO AIR PAD DISTRIBUTOR J-BOX - PANEL & BACKPANEL LAYOUT
9222A-7 - 121	JB120 SILO AIR PAD DISTRIBUTOR J-BOX - BILL OF MATERIAL, TERMINAL LAYOUT & LEGEND
9222A-7 - 122	JB120 SILO AIR PAD DISTRIBUTOR J-BOX - WIRING DIAGRAM
9222A-7 - 123	SPARE DRAWINGS - (SHEETS 123-198)
9222A-7 - 124	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 125	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 126	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 127	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 128	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 129	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 130	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 131	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 132	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 133	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 134	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 135	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 136	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 137	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 138	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 139	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 140	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 141	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 142	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 143	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 144	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 145	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 146	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 147	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 148	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 149	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 150	SPARE DRAWING - SHEET NOT IN DRAWING SET

DRAWING NUMBER	DESCRIPTION
9222A-7 - 151	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 152	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 153	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 154	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 155	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 156	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 157	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 158	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 159	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 160	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 161	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 162	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 163	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 164	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 165	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 166	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 167	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 168	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 169	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 170	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 171	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 172	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 173	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 174	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 175	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 176	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 177	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 178	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 179	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 180	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 181	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 182	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 183	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 184	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 185	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 186	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 187	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 188	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 189	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 190	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 191	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 192	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 193	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 194	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 195	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 196	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 197	SPARE DRAWING - SHEET NOT IN DRAWING SET
9222A-7 - 198	SPARE DRAWING - SHEET NOT IN DRAWING SET

						CONTROL SYSTEM			 <div><b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA www.nol-tec.com (651) 780-8600 #280</div>	
						DRAWING INDEX				
						DESERT VIEW POWER UNIT A & B				
						MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 02.Aug.14	CATALOG NO.
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE	
										DRAWING NO.
										9222A-7-004

SHEETS 05-09 ARE RESERVED FOR FUTURE USE

			SPARE			 <b>NOL-TEC</b> SYSTEMS <small>Lino Lakes, MN - USA (851) 780-8560 ©2007</small>
			DRAWING			
			DESERT VIEW POWER UNIT A & B			
			MECCA, CA			
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	CATALOG NO.
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	DRAWING NO.
					DATE 06.Aug.14	9222A-7-004
					SCALE NONE	







SHEETS 12-14 ARE RESERVED FOR FUTURE USE


						SPARE		 <b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA (851) 780-8660 <a href="http://www.nol-tec.com">www.nol-tec.com</a>
						DRAWING		
						DESERT VIEW POWER UNIT A & B		
						MECCA, CA		
0	28JAN16	ISSUED FOR CONSTRUCTION		JVE	JAB	DRAWN BY J. ELLWEIN		CATALOG NO.
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY J. BROWN		DRAWING NO.
						DATE 06.Aug.14		9222A-7-012
						SCALE NONE		


Diagram illustrating the network configuration for the Allen-Bradley PowerFlex 523 VFDs. The VFDs are connected to a common N-Tron 116T-X terminal block, which is connected to a Grace Programming Receptacle. The IP addresses assigned to each VFD are as follows:

VFD Label	IP Address
INJECTION BLOWER 1 VFD	10.10.10.10
INJECTION BLOWER 2 VFD	10.10.10.12
PIG UNLOAD BLOWER VFD	10.10.10.11
LIW HOPPER 1 FEED SCREW	10.10.10.13
LIW HOPPER 1 AGITATOR	10.10.10.14
LIW HOPPER 2 FEED SCREW	10.10.10.15
LIW HOPPER 2 AGITATOR	10.10.10.16

The diagram illustrates the hardware configuration and wiring for the Allen-Bradley PanelView Plus 1000 Touch HMI system. The components and their connections are as follows:

- Allen-Bradley PanelView Plus 1000 Touch:** The HMI unit is connected to the CompactLogix rack via a cable.
- Allen-Bradley CompactLogix Rack:** The rack contains several modules, including a power supply and communication modules. It is connected to the 1161X terminal block.
- 1161X Terminal Block:** A 16-pin terminal block used for connecting the HMI, rack, and weigh controllers. The connections are:
  - Pin 1: IP ADDRESS 10.10.10.1
  - Pin 2: IP ADDRESS 10.10.10.3
  - Pin 3: IP ADDRESS 10.10.10.4
  - Pin 4: IP ADDRESS 10.10.10.5
  - Pin 5: IP ADDRESS 10.10.10.6
- LIW Hopper 1 Weigh Controller:** Connected to the 1161X terminal block via a cable.
- LIW Hopper 2 Weigh Controller:** Connected to the 1161X terminal block via a cable.

Diagram illustrating the connection of a 1756-ENB module to the CompactLogix Rack. The rack is shown with three slots, each containing a 1756-ENB module. The rack is connected to a 1756-ENB module via a 1756-ENB-1 cable. The rack is also connected to a 1756-ENB module via a 1756-ENB-2 cable. The rack is connected to a 1756-ENB module via a 1756-ENB-3 cable.

		CONTROL SYSTEM				 <b>NOL-TEC</b> SYSTEMS Little Lakes, MN - USA www.nol-tec.com (651) 780-8600 © 2007		
		ETHERNET ARCHITECTURE						
		DESERT VIEW POWER UNIT A & B						
		MECCA, CA						
0	28JAN16	ISSUED FOR CONSTRUCTION		JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE	
								DRAWING NO. <b>9222A-7-015</b>

SHEETS 16-19 ARE RESERVED FOR FUTURE USE


[illegible]





NOL-TEC SYSTEMS INC. JOBSCOPE CATALOG •67603					
ITEM	QTY.	DESCRIPTION	MANUFACTURER	MANUFACTURERS PART No.	NOLTEC No.
1	1	ENCLOSURE, NEMA 12, 72.00" x 78.00" x 18.00" W/ 60.00" x 72.00" BACKPANEL	HOFFMAN	A72XM7818SSN4	31050
2	1	SHELF, FOLDING, 18.00" x 18.00"	HOFFMAN	AASHLF1818	13922
3	1	OPERATOR ADAPTER FOR HOFFMAN ENCLOSURE	ALLEN-BRADLEY	ABS	67536
4	1	140G-MOLDED CASE CIRCUIT BREAKER, K FRAME, 65 kA, T/M-THERMAL MAGNETIC, RATED CURRENT 400 A	ALLEN-BRADLEY	140G-K6F3-D40	67534
5	1	140G FLEX-CABLE MECHANISM, STAINLESS STEEL FLANGE HANDLE, 4 FT	ALLEN-BRADLEY	140G-K-FCS04	67535
6	2	FRAME-K, TERMINAL LUG, QTY 3, FCCuAL 1x250-500(120-240)	ALLEN-BRADLEY	140G-K-TLA1A3	67606
7	1	POWER DISTRIBUTION BLOCK, 420 A, 3 POLE LINE (1) 600MCM, LOAD (12) 4-14	BUSSMANN	163375-3	33945
8	2	POWER DISTRIBUTION BLOCK, COVER, 3 POLE FOR 163 SERIES	BUSSMANN	CPDB-3	33943
9	1	CIRCUIT BREAKER, 3 POLE, 60 AT, 65KA THERMAL MAGNETIC, G-FRAME	ALLEN-BRADLEY	140G-G6C3-C60	64808
10	3	CIRCUIT BREAKER, MOTOR PROTECTION, 32 - 45 AMPS	ALLEN-BRADLEY	140M-F8E-C45	36769
11	3	VFD DRIVE, 480VAC, 3 PHASE, 20 HP, POWERFLEX 523	ALLEN-BRADLEY	25A-D030N104	67607
12	4	CIRCUIT BREAKER, MOTOR PROTECTION, 4.0 - 6.3 AMPS	ALLEN-BRADLEY	140M-C2E-B63	36115
13	4	VFD DRIVE, 480VAC, 3 PHASE, 2 HP, POWERFLEX 523	ALLEN-BRADLEY	25A-D4PON104	67608
14	7	COMMUNICATION MODULE, POWERFLEX 525, ETHERNET/IP COMMUNICATIONS ADAPTER	ALLEN-BRADLEY	25-COMM-E2P	60996
15	4	CIRCUIT BREAKER, MOTOR PROTECTION, 2.5 - 4.0 AMPS	ALLEN-BRADLEY	140M-C2E-B40	39569
16	1	CIRCUIT BREAKER, MOTOR PROTECTION, 4.0 - 6.3 AMPS	ALLEN-BRADLEY	140M-C2E-B63	36115
17	5	MOTOR CIRCUIT PROTECTOR, AUXILIARY, FRONT MOUNT, CONTACT 1NO, 1NC	ALLEN-BRADLEY	140M-C-AFA11	42411
18	5	CONTACTOR, 3 POLE, 1NO AUX CONTACT, NON-REVERSING, 24VDC, COIL, 9 AMP	ALLEN-BRADLEY	100-C09EJ10	48169
19	4	RELAY, OVERLOAD, 1-5 AMP, SOLID STATE AUTO/MAN RESET	ALLEN-BRADLEY	193-EECB	45044
20	1	RELAY, OVERLOAD, 3.2-16 AMP, SOLID STATE AUTO/MAN RESET	ALLEN-BRADLEY	193-EEDB	53622
21	2	CIRCUIT BREAKER, 2 POLE, 5 AMP, THERMAL MAGNETIC	ALLEN-BRADLEY	140U-D6D2-B50	67610
22	3	CIRCUIT BREAKER 1 POLE, 20 AMP DIN, C-TRIP	ALLEN-BRADLEY	1489-MIC200	61533
23	1	CIRCUIT BREAKER, 1 POLE, 10 AMP DIN, C-TRIP	ALLEN-BRADLEY	1489-MIC100	63393
24	3	TERMINAL BLOCK, FUSIBLE W/NEON IND 100-300VAC	ALLEN-BRADLEY	1492-H4	15105
25	3	END BARRIER, (1492-H4 THRU H7)	ALLEN-BRADLEY	1492-N37	10289
26	6	FUSE, 250V, 5 AMP, CERAMIC, FAST ACTING	BUSSMANN	ABC-5	32614
27	1	TERMINAL BLOCK, 600 V, 50 A, GRAY	ALLEN-BRADLEY	1492-J6	41154
28	4	END BARRIER (USED ON 1492-J3, J4, J6 & J10) GRAY	ALLEN-BRADLEY	1492-EBJ3	41900
29	30	TERMINAL BLOCK, 22-12 AWG, 600 V, BLUE	ALLEN-BRADLEY	1492-J4-B	41772
30	3	END BARRIER (USED ON 1492-J3, J4, J6 & J10), BLUE	ALLEN-BRADLEY	1492-EBJ3-B	45134
32	4	JUMPER BAR, CENTER, 10 POLE, FOR 1492-J4	ALLEN-BRADLEY	1492-CJJ6-10	41906
33	35	END ANCHOR, DIN RAIL, HEAVY DUTY	ALLEN-BRADLEY	1492-EAHJ35	41899
34	9	END ANCHOR, DIN RAIL, J-SERIES, STANDARD DUTY	ALLEN-BRADLEY	1492-EAJ35	42412
35	1	TERMINAL BLOCK, GROUNDING	ALLEN-BRADLEY	1492-JG6	41904
36	2	GROUND BAR	CUTLER-HAMMER	GBK5	10404
37	1	GROUND BAR, VERTICLE RACK BUS BAR 0.25" X 0.62" X 36" W/ PRE PUNCHED HOLES	STORM COPPER	SCGB-R62-36	49825
39	192"	DIN RAIL	ALLEN-BRADLEY	199-DR1	10220
40	216"	WIRE DUCT, 4" WD X 4" DEEP, WHT	THOMAS & BETTS	TY4X4NPW6	43650
41	216"	WIRE DUCT, COVER, 4" WD, WHT	THOMAS & BETTS	TY4CPW6	43654
42	360"	WIRE DUCT, 2" WD X 4" DEEP, WHT	THOMAS & BETTS	TY2X4NPW6	43647
43	360"	WIRE DUCT, COVER, 2" WD, WHT	THOMAS & BETTS	TY2CPW6	43652
44	2	ENCLOSURE, DOOR STOP KIT, FOR LARGE ENCLOSURES	HOFFMAN	ALGDSTOP2	48275
45	2	TERMINAL BLOCK, FUSIBLE W/ LED INDICAOTR, 10-57V AC/DC	ALLEN-BRADLEY	1492-H5	24557
48	1	ETHERNET SWITCH, 16 10/100 MBT PORTS RJ45 CONNECTORS, 24VDC SUPPLY, DIN MOUNT	N-TRON	116TX	54459
49	1	RECEPTACLE, 120VAC, GFI, W/ETHERNET 10/100 RJ45	GRACE ENGINEERING	P-R33-M2RF0	32608
50	1	POWER SUPPLY, THREE PHASE INPUT, 24VDC SECONDARY, 20 AMP, 480 WATTS	ALLEN-BRADLEY	1606-XL480E-3	50975
51	7	LEGEND - AS REQUIRED BY JOB - PLASTIC	PER PRINT/LIST	LEGEND	64382
52	1	SURGE SUPPRESSOR, 120 VAC, 20 AMP, DUPLEX OUTLET INCLUDED	TRANSECTOR SYSTEMS	ACP-100-DR2-20A	50783
53	1	AIR CONDITIONER, 6000 BTUH, 480VAC/1.8 AMP, W/ MALFUNCTION SWITCH, RAZOR SERIES	ISC SALES	RZ-06A-486-4X	67616
54	2	LIGHT, ENCLOSURE, LED, 120VAC, ON/OFF SWITCH	HOFFMAN	LEDAIS35	67619
55	2	LIGHTING PACKAGE, DOOR SWITCH, FRAME MOUNTED	HOFFMAN	PLFSWD	67225
56	30	TERMINAL BLOCK, 22-10 AWG, 600V, 35 AMP	ALLEN-BRADLEY	1492-J4	41310
57	5	CABLE, ETHERNET, CAT 5E PATCH, 20 FT, BLUE RJ45 TO RJ45, SNAGLESS	BELKIN	A3L791-20-BLU-S	47492
58	4	CABLE, ETHERNET, CAT 5E PATCH, 10 FT, BLUE RJ45 TO RJ45, SNAGLESS	BELKIN	A3L791-10-BLU-S	53168
59	1	POWER SUPPLY, 2.5 AMP, 24VDC, DIN MOUNT	SOLA/HEVIDUTY	SDN 2.5-24-100P	21614
60	1	CIRCUIT BREAKER, MOTOR PROTECTION, 1.6 - 2.5 AMPS	ALLEN-BRADLEY	140M-C2E-B25	36770

						CP020 MOTOR CONTROL PANEL	
						BILL OF MATERIAL	
						DESERT VIEW POWER UNIT A & B	
						MECCA, CA	
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.14	CATALOG NO.
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE	67603



NOL-TEC

SYSTEMS

Lino Lakes, MN - USA



www.nol-tec.com

(651) 780-8800

©2011


9222A-7-022







--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--









						CP020 MOTOR CONTROL PANEL			 <b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA (651) 780-8500 www.nol-tec.com ©2007	
						480VAC POWER DISTRIBUTION				
						DESERT VIEW POWER UNIT A & B				
						MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.14	CATALOG NO. <b>9222A-7-025</b>
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE	




SHEET 27 IS RESERVED FOR FUTURE USE




					SPARE				 <b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA www.nol-tec.com (851) 780-8660 ©2007
					DRAWING				
					DESERT VIEW POWER UNIT A & B MECCA, CA				
O	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN	DATE: 06.Aug.14	CATALOG NO.
REV.	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE	
								DRAWING NO.	
								9222A-7-027	



										 <div><b>NOL-TEC</b> SYSTEMS <small>Lino Lakes, MN - USA</small> <a href="http://www.nol-tec.com">www.nol-tec.com</a> <small>(651) 780-8600</small> <small>©2007</small></div>


SHEET 29 IS RESERVED FOR FUTURE USE

				SPARE				 <b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA (651) 780-8500 www.nol-tec.com ©2007	
				DRAWING					
				DESERT VIEW POWER UNIT A & B					
				MECCA, CA					
0	28JAN16	ISSUED FOR CONSTRUCTION		JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.14	CATALOG NO.
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE	
									DRAWING NO. <b>9222A-7-029</b>




AWI MANUFACTURING  
72X36X18 ENCLOSURE  
WITH AWNING,  
WINDOW KIT AND  
BACKPANEL

NOTE:  
HUBBELL ETHERNET CONNECTOR IS TO BE  
MOUNTED TO TOP OF ENCLOSURE NEAR  
THE RIGHT SIDE.

CP030 PLC CONTROL PANEL										 <b>NOL-TEC</b> SYSTEMS <small>Lino Lakes, MN - USA (651) 750-8600 www.nol-tec.com ©2007</small>	
PANEL LAYOUT											
DESERT VIEW POWER UNIT A & B											
MECCA, CA											
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.	67623	
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 3/16"=1"	DRAWING NO.		
											9222A-7-030






AWI MANUFACTURING  
72X36X18 ENCLOSURE  
WITH AWNING  
WINDOW KIT, AND  
BACKPANEL

				CP030 PLC CONTROL PANEL			
				BACKPANEL LAYOUT			
				DESERT VIEW POWER UNIT A & B			
				MECCA, CA			
0	28JAN16	ISSUED FOR CONSTRUCTION		JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.14
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 1/4"=1"
						CATALOG NO.	67623
						DRAWING NO.	9222A-7-031



NOL-TEC SYSTEMS INC. JOBSCOPE CATALOG •67623					
ITEM	QTY.	DESCRIPTION	MANUFACTURER	MANUFACTURER PART No.	NOL-TEC No.
1	1	ENCLOSURE, NEMA 4X STAINLESS STEEL, 72" X 36" X 18", FREE STANDING, SINGLE DOOR ACCESS	HOFFMAN	A723618SSFSN4	15980
2	1	BACK PANEL, 72" X 36" FULL LENGTH, FREE STANDING ENCLOSURE	HOFFMAN	A72P36F1	15981
3	1	OPERATOR INTERFACE, PANELVIEW PLUS 1000 COLOR, TOUCH, ETHERNET, DC PS	ALLEN-BRADLEY	2711P-T10C4D8	55975
4	1	POWER SUPPLY, COMPACT LOGIX, 4A @ 5V, 2A @ 24 VDC, 24VDC	ALLEN-BRADLEY	1769-PB4	50851
5	1	COMPACTLOGIX, PROCESSOR, W/2 MB MEMORY USE WITH COMPACTLOGIX I/O - ETHERNET	ALLEN-BRADLEY	1769-L33ER	59428
6	3	INPUT MODULE, COMPACT LOGIX, 16 PT DC	ALLEN-BRADLEY	1769-IQ16	56128
7	3	OUTPUT MODULE, COPACT LOGIX, 16 PT DC OUT	ALLEN-BRADLEY	1769-OB16	37605
8	4	INPUT MODULE, ANALOG, COMPACT LOGIX 8 PT VOLTAGE/CURRENT	ALLEN-BRADLEY	1769-IF8	41312
9	1	ETHERNET/IP ADAPTER	ALLEN-BRADLEY	1769-AENTR	67635
10	1	TERMINATOR RIGHT END CAP, MICROLOGIX	ALLEN-BRADLEY	1769-ECR	28721
11	1	ETHERNET SWITCH, 16 10/100 MBT PORTS RJ45 CONNECTORS, 24VDC SUPPLY, DIN MOUNT	N-TRON	116TX	54459
12	1	INDUSTRIAL MEDIA CONVERTER, ST 2KM, 10/100BASE TX->100BASEFX MULTIMODE FIBER	N-TRON	102MC-ST	65601
13	1	CIRCUIT BREAKER, 1 POLE, 10 AMP DIN, C-TRIP	ALLEN-BRADLEY	1489-M1C100	63393
14	1	CIRCUIT BREAKER, 1 POLE, 20 AMP DIN, C-TRIP	ALLEN-BRADLEY	1489-M1C200	61533
15	57	TERMINAL BLOCK, FUSIBLE W/LED INDICATOR 10-57V AC/DC	ALLEN-BRADLEY	1492-H5	24557
16	2	TERMINAL BLOCK, 600 V, 50 A, BLUE	ALLEN-BRADLEY	1492-J6B	48127
17	1	TERMINAL BLOCK, GROUNDING	ALLEN-BRADLEY	1492-JG6	41904
18	180	TERMINAL BLOCK, 22-12 AWG, 600 V, BLUE	ALLEN-BRADLEY	1492-J4-B	41772
19	18	TERMINAL BLOCK, GROUNDING	ALLEN-BRADLEY	1492-JG4	41903
20	4	END BARRIER, (1492-H4 THRU H4)	ALLEN-BRADLEY	1492-N37	10289
21	12	END BARRIER (USED ON 1492-J3, J4, J6 & J10), BLUE	ALLEN-BRADLEY	1492-EBJ3-B	45134
22	10	JUMPER BAR, CNETER, 10 POLE, FOR 1492-J4	ALLEN-BRADLEY	1492-CJJ6-10	41906
23	14	END ANCHOR, DIN RAIL, J-SERIES, STANDARD DUTY	ALLEN-BRADLEY	1492-EAJ35	42412
24	2	FUSE, 250 V, 10 AMP, CERAMIC, FAST ACTING	BUSSMANN	ABC-10	32659
25	6	FUSE, 250V, 5 AMP, CERAMIC, FAST ACTING	BUSSMANN	ABC-5	32614
26	4	FUSE, 250 V, 2 AMP, CERAMIC, 1/4" x 1 1/4"	BUSSMANN	ABC-2	16194
27	65	FUSE, 250 V, 1 AMP, CERAMIC, FAST ACTING	BUSSMANN	ABC-1	15078
28	6	GROUND BAR	CUTLER-HAMMER	GBK5	10404
29	155"	DIN RAIL, HI-RISE, ALUMINUM COPPER FREE ALUM	ALLEN-BRADLEY	1492-DR6	23743
30	220"	WIRE DUCT 2" WD X 4" DEEP, WHT	THOMAS & BETTS	TY2X4NPW6	43647
31	220"	WIRE DUCT, COVER, 2" WD, WHT	THOMAS & BETTS	TY2CPW6	43652
32	96"	WIRE DUCT 4" WD X 4" DEEP, WHT	THOMAS & BETTS	TY4X4NPW6	43650
33	96"	WIRE DUCT, COVER, 4" WD, WHT	THOMAS & BETTS	TY4XPW6	43654
34	1	ENCLOSURE, DOOR STOP KIT, FOR LARGE ENCLOSURES	HOFFMAN	ALGDSTOP2	48275
35	5	CABLE, ETHERNET, CAT 5E PATCH, 20 FT, BLUE RJ45 TO RJ45, SNAGLESS	BELKIN	A3L791-20-BLU-S	47492
36	4	CABLE, ETHERNET, CAT 5E PATCH, 10 FT, BLUE RJ45 TO RJ45, SNAGLESS	BELKIN	A3L791-10-BLU-S	53168
38	2	WEIGH SCALE CONTROLLER, PANEL MOUNT 24 VDC, AB TCP-IP, ROD INCLUDED	HARDY INSTRUMENTS	4050-PM-DC-EIP-ROC	50776
39	4	LEGEND - AS REQUIRED BY JOB - PLASTIC	PER PRINT/LIST	LEGEND	64382
40	1	HOFFMAN LED LIGHT KIT	HOFFMAN	LEDD1S35	67632
41	1	HOFFMAN LIGHT SWITCH	HOFFMAN	PLFSWD	67225
42	1	HEAT EXCHANGER, 2000 BTU, NEMA 4X, 480VAC	ISC SALES	RZ-02A-486-4X	67617
43	1	AWNING, 25" X 13.5", SS	AWI MFG.	QUOTE •46976	64726
44	1	WINDOW KIT, 22.1875" X 16.125" X 2.75"	AWI MFG.	QUOTE •46976	64724
45	36"	DIN RAIL	ALLEN-BRADLEY	199-DR1	10220

									CP030 PLC CONTROL PANEL
									BILL OF MATERIAL
									DESERT VIEW POWER UNIT A & B
									MECCA, CA
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.14	CATALOG NO.		
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE	67623		





**NOL-TEC**  
SYSTEMS  
www.nol-tec.com

Lino Lakes, MN - USA  
(651) 780-8800  
©2001


9222A-7-032








									CP030 PLC CONTROL PANEL	
									24VDC POWER DISTRIBUTION	
									DESERT VIEW POWER UNIT A & B	
									MECCA, CA	
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.			
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE				

**NOL-TEC**  
SYSTEMS  
Lino Lakes, MN - USA  
www.nol-tec.com (651) 780-8600

DRAWING NO.  
**9222A-7-034**

SHEETS 35-39 ARE RESERVED FOR FUTURE USE

[illegible]







INPUT


**NOL-TEC**  
SYSTEMS Lino Lakes, MN • USA  
[www.nol-tec.com](http://www.nol-tec.com) (651) 780-8600  
© 2007














					CP030 PLC CONTROL PANEL					 <b>NOL-TEC</b> SYSTEMS <small>Lino Lakes, MN - USA</small> <a href="http://www.nol-tec.com">www.nol-tec.com</a> <small>(651) 760-8600</small> <small>© 2007</small>	
					I/O WIRING DIAGRAM MODULE 7 & 8						
					DESERT VIEW POWER UNIT A & B						
					MECCA, CA						
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.15	CATALOG NO.	DRAWING NO. <b>9222A-7-044</b>
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE		






				CP030 PLC CONTROL PANEL				 <b>NOL-TEC</b> SYSTEMS Line Lakes, MN - USA www.nol-tec.com (651) 780-8600 © 2007	
				I/O WIRING DIAGRAM MODULE 9 & 10					
				DESERT VIEW POWER UNIT A & B					
				MECCA, CA					
0	28JAN16	ISSUED FOR CONSTRUCTION		JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.15	
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE	
								CATALOG NO.	9222A-7-045


00  
  
02  
  
04  
  
06  
  
08  
  
10  
  
12  
  
14  
  
16  
  
18  
  
20  
  
22  
  
24  
  
26  
  
28  
  
30  
  
32  
  
34


40  
  
42  
  
44  
  
46  
  
48  
  
50  
  
52  
  
54  
  
56  
  
58  
  
60  
  
62  
  
64  
  
66  
  
68  
  
70  
  
72  
  
74

					CP030 PLC CONTROL PANEL				 <b>NOL-TEC</b> SYSTEMS <small>Lino Lakes, MN • USA www.nol-tec.com (651) 780-8800 ©2011</small>	
					I/O WIRING DIAGRAM MODULE ETHERNET					
					DESERT VIEW POWER UNIT A & B					
					MECCA, CA					
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN			DATE 06.Aug.14
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE	
DRAWING NO. 9222A-7-046										

SHEETS 47-49 ARE RESERVED FOR FUTURE USE


[illegible]



							CP050 PIG REMOTE I/O PANEL PANEL & BACKPANEL LAYOUT DESERT VIEW POWER UNIT A & B MECCA, CA	 <b>NOL-TEC SYSTEMS</b> Line Lakes, MN - USA <a href="http://www.nol-tec.com">www.nol-tec.com</a> (651) 780-8600 ©2007
O	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.14	CATALOG NO.	DRAWING NO.
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 1/2"=1"	67626	9222A-7-050

NOL-TEC SYSTEMS INC. JOBSCOPE CATALOG •67626					
ITEM	QTY.	DESCRIPTION	MANUFACTURER	PART No.	NOL-TEC No.
1	1	ENCLOSURE, NEMA 4X, 24" X 20" X 8", 304SS	HOFFMAN	A24H2008SSLP	24522
2	1	BACK PANEL, 21.00" X 17.00"	HOFFMAN	A24P20	17731
3	1	FLEX I/O ETHERNET ADAPTER MODULE W/24VDC POWER SUPPLY	ALLEN-BRADLEY	1794-AENT	40057
4	4	FLEX I/O TERMINAL WIRING BASE	ALLEN-BRADLEY	1794-TB3	23347
5	2	FLEX I/O 16-POINT, 24 VDC, INPUT MODULE SINK (SOURCE LOAD)	ALLEN-BRADLEY	1794-IB16	34000
6	2	FLEX I/O 16-POINT, 24 VDC, OUTPUT MODULE SOURCE	ALLEN-BRADLEY	1794-OB16	34001
7	2	CIRCUIT BREAKER, 1 POLE, 10 AMP DIN, C-TRIP	ALLEN-BRADLEY	1489-M1C100	63393
8	5	TERMINAL BLOCK, FUSIBLE W/LED INDICATOR 10-57V AC/DC	ALLEN-BRADLEY	1492-H5	24557
9	1	END BARRIER, (1492-H4 THRU H7)	ALLEN-BRADLEY	1492-N37	10289
10	4	FUSE, 250 V, 5 AMP, CERAMIC, 1/4" X 1 1/4", FAST ACTING	BUSSMANN	ABC-5	32614
11	2	FUSE, 250 V, 2 AMP, CERAMIC, 1/4" X 1 1/4", FAST ACTING	BUSSMANN	ABC-2	16194
12	32	TERMINAL BLOCK, 300 V, 35 A, BLUE	ALLEN-BRADLEY	1492-J4-B	41772
13	1	TERMINAL BLOCK, GROUNDING	ALLEN-BRADLEY	1492-JG4	41903
15	4	END BARRIER (USED ON 1492-J3, J4, J6, & J10), BLUE	ALLEN-BRADLEY	1492-EBJ3-B	41534
16	2	END ANCHOR, DIN RAIL, J-SERIES, STANDARD DUTY	ALLEN-BRADLEY	1492-EAJ35	42412
17	3	JUMPER BAR, CENTER, 10 POLE, FOR 1492-J4	ALLEN-BRADLEY	1492-CJJ6-10	41906
18	2	GROUND BAR	CUTLER-HAMMER	CBK5	10404
19	48"	DIN RAIL	ALLEN-BRADLEY	199-DR1	10220
20	48"	WIRE DUCT, 2" WD X 3" DEEP, WHT	THOMAS & BETTS	TY2X3NPW6	43646
21	48"	WIRE DUCT, COVER, 2" WD, WHT	THOMAS & BETTS	TY2CPW6	43652
22	24"	WIRE DUCT, 1" WD X 3" DEEP, WHT	THOMAS & BETTS	TY1X3NPW6	43644
23	24"	WIRE DUCT, COVER, 1" WD, WHT	THOMAS & BETTS	TY1CPW6	43651
24	1	LEGEND - AS REQUIRED BY JOB - PLASTIC	PER PRINT/LIST	LEGEND	64382
25	1	LEGEND - MASK FOR ENCLOSURE	CONTROL CENTER	QUOTE •	-
26	6	PUSH BUTTON/PILOT LIGHT, OPERATOR, 12-120V, ROUND, EXTENDED, NEMA 4/4X/13	ALLEN-BRADLEY	800B-EPA	67641
27	6	PILOT LIGHT LENS, RED, ROUND	ALLEN-BRADLEY	800B-ALA4	67561
29	6	LAMP, LED, RED, 12/24V AC/DC	ALLEN-BRADLEY	800B-N3R	67560
30	6	CONTACT BLOCK, PILOT LIGHT	ALLEN-BRADLEY	800B-PL	67559

									CP050 PIG REMOTE I/O PANEL	
									BILL OF MATERIAL	
									DESERT VIEW POWER UNIT A & B	
									MECCA, CA	
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.14	CATALOG NO.			
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE	67626			



**NOL-TEC**  
SYSTEMS  
www.nol-tec.com (851) 780-8800 42001

DRAWING NO.  
**9222A-7-051**

LEGENDS FOR DOOR LAYOUT							
No.	Qty.	LINE #1	LINE #2	LEGEND SIZE	LETTER SIZE	TAG COLOR	TEXT COLOR
1	1	CP050	.	¾" x 4"	½"	WHITE	BLACK

1 CP050

TB2	
	02852
	02625
	GND
	CB-05300
	CB-05302
	FU-05310
	FU-05316
	FU-05318
	FU-05600
	FU-05640
	05300
	05300
	05300
	05300
	05300
	05302
	05302
	05302
	05302
	05302
	02625
	02625
	02625
	02625
	02625
	02625
	02625
	02625
	02625
	02625

STICKERS TO BE MOUNTED TO THE INTERIOR OF THE DOOR


CB & FUSE CHART	
CB-05300	10 AMP
CB-05302	10 AMP
FU-05310	2 AMP
FU-05316	5 AMP
FU-05318	5 AMP
FU-05600	5 AMP
FU-05640	5 AMP

JOB #9222A
CONTROL VOLTAGE = 24VDC
TOTAL FULL LOAD AMPS = 10

HOLES IN ENCLOSURE  
MUST BE FILLED WITH  
NEMA TYPE 4X DEVICES


WIRING TERMINALS USE  
COPPER WIRE WITH  
60 DEG C INSULATION

TERMINAL BLOCK  
TIGHTENING TORQUE  
600V 4.4-8.8 LB-IN  
600V 7.1-12.4 LB-IN  
300V 3-7 LB-IN

						CP050 PIG REMOTE I/O PANEL			 <div><b>NOL-TEC</b> SYSTEMS www.nol-tec.com Lino Lakes, MN • USA (651) 780-8800 ©2011</div>		
						TERMINAL LAYOUT & LEGENDS					
						DESERT VIEW POWER UNIT A & B					
						MECCA, CA					
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.14	CATALOG NO.	9222A-7-052
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE	67626	



SHEET 54 IS RESERVED FOR FUTURE USE


			SPARE			 <b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA (651) 780-8500 www.nol-tec.com ©2007	
			DRAWING				
			DESERT VIEW POWER UNIT A & B				
			MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.14	CATALOG NO.
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE	
							DRAWING NO. <b>9222A-7-054</b>









SHEETS 57-59 ARE RESERVED FOR FUTURE USE


					SPARE		 <b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA <a href="http://www.nol-tec.com">www.nol-tec.com</a> (851) 780-8560 ©2007
					DRAWING		
					DESERT VIEW POWER UNIT A & B		
					MECCA, CA		
O	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	
REV.	DATE	REVISION NOTE			DRAWN	DESIGN	
					DRAWN BY J. ELLWEIN	DATE 06.Aug.14	CATALOG NO.
					DESIGN BY J. BROWN	CATALOG NO.	

NOL-TEC SYSTEMS INC. JOBSCOPE CATALOG *				
ITEM	QTY.	DESCRIPTION	MANUFACTURER	PART No.
1	1	UNFUSED DISCONNECT SWITCH 30 A	ALLEN BRADLEY	194R-CN30-1753-PY
2	1	LEGEND - AS REQUIRED BY JOB - PLASTIC	PER PRINT/LIST	LEGEND

LEGENDS FOR DOOR LAYOUT							
No.	Qty.	LINE #1	LINE #2	LEGEND SIZE	LETTER SIZE	TAG COLOR	TEXT COLOR
1	1	FD060	.	¾" x 4"	½"	WHITE	BLACK

1 FD060



					INJECTION BLOWER 1			 <b>NOL-TEC</b> SYSTEMS www.nol-tec.com Lino Lakes, MN - USA (651) 780-8600 #280	
					FIELD DISCONNECT FD060				
					DESERT VIEW POWER UNIT A & B				
					MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.  9222A-7-060
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 1"=1"	







NOL-TEC SYSTEMS INC. JOBSCOPE CATALOG *				
ITEM	QTY.	DESCRIPTION	MANUFACTURER	PART No.
1	1	UNFUSED DISCONNECT SWITCH 30 A	ALLEN BRADLEY	194R-CN30-1753-PY
2	1	LEGEND - AS REQUIRED BY JOB - PLASTIC	PER PRINT/LIST	LEGEND

LEGENDS FOR DOOR LAYOUT							
No.	Qty.	LINE •1	LINE •2	LEGEND SIZE	LETTER SIZE	TAG COLOR	TEXT COLOR
1	1	FD062	.	3/4" x 4"	1/2"	WHITE	BLACK

1 FD062



								PIG UNLOAD BLOWER				 <b>NOL-TEC SYSTEMS</b> Little Lakes, MN - USA www.nol-tec.com (857) 730-8690 ©2007
								FIELD DISCONNECT FD062				
								DESERT VIEW POWER UNIT A & B				
								MECCA, CA				
O	26JAN16	ISSUED FOR CONSTRUCTION				JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.	DRAWING NO.	
REV	DATE	REVISION NOTE				DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 1"=1"		9222A-7-062	












NOL-TEC SYSTEMS INC. JOBSCOPE CATALOG *				
ITEM	QTY.	DESCRIPTION	MANUFACTURER	PART No.
1	1	UNFUSED DISCONNECT SWITCH 30 A	ALLEN BRADLEY	194R-CN30-1753-PY
2	1	LEGEND - AS REQUIRED BY JOB - PLASTIC	PER PRINT/LIST	LEGEND

LEGENDS FOR DOOR LAYOUT							
No.	Qty.	LINE #1	LINE #2	LEGEND SIZE	LETTER SIZE	TAG COLOR	TEXT COLOR
1	1	FD065	.	¾" x 4"	½"	WHITE	BLACK

1 FD065






				HEAT EXCHANGER 1				 <b>NOL-TEC</b> SYSTEMS www.nol-tec.com Lino Lakes, MN - USA (651) 780-8600 #280	
				FIELD DISCONNECT FD065					
				DESERT VIEW POWER UNIT A & B					
				MECCA, CA					
0	28JAN16	ISSUED FOR CONSTRUCTION		JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15		CATALOG NO.
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 1"=1"		
								DRAWING NO.	9222A-7-065

NOL-TEC SYSTEMS INC. JOBSCOPE CATALOG *				
ITEM	QTY.	DESCRIPTION	MANUFACTURER	PART No.
1	1	UNFUSED DISCONNECT SWITCH 30 A	ALLEN BRADLEY	194R-CN30-1753-PY
2	1	LEGEND - AS REQUIRED BY JOB - PLASTIC	PER PRINT/LIST	LEGEND

LEGENDS FOR DOOR LAYOUT							
No.	Qty.	LINE #1	LINE #2	LEGEND SIZE	LETTER SIZE	TAG COLOR	TEXT COLOR
1	1	FD066	.	¾" x 4"	½"	WHITE	BLACK

1 FD066





				HEAT EXCHANGER 2				 <b>NOL-TEC</b> SYSTEMS www.nol-tec.com Lino Lakes, MN - USA (651) 780-8600 #280
				FIELD DISCONNECT FD066				
				DESERT VIEW POWER UNIT A & B				
				MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION		JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 1"=1"	DRAWING NO.
								9222A-7-066




NOL-TEC SYSTEMS INC. JOBSCOPE CATALOG *				
ITEM	QTY.	DESCRIPTION	MANUFACTURER	PART No.
1	1	UNFUSED DISCONNECT SWITCH 30 A	ALLEN BRADLEY	194R-CN30-1753-PY
2	1	LEGEND - AS REQUIRED BY JOB - PLASTIC	PER PRINT/LIST	LEGEND

LEGENDS FOR DOOR LAYOUT							
No.	Qty.	LINE •1	LINE •2	LEGEND SIZE	LETTER SIZE	TAG COLOR	TEXT COLOR
1	1	FD067	.	$\frac{3}{4}$ " x 4"	$\frac{1}{2}$ "	WHITE	BLACK

1 FD067



						LIW HOPPER 1 AGITATOR				<b>NOL-TEC</b> SYSTEMS www.nol-tec.com	Lino Lakes, MN - USA (651) 730-8600 © 2007
						FIELD DISCONNECT FD067					
						DESERT VIEW POWER UNIT A & B MECCA, CA					
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.	DRAWING NO. 9222A-7-067	
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 1"=1"			





DRAWING NO.  
9222A-7-067




NOL-TEC SYSTEMS INC. JOBSCOPE CATALOG *				
ITEM	QTY.	DESCRIPTION	MANUFACTURER	PART No.
1	1	UNFUSED DISCONNECT SWITCH 30 A	ALLEN BRADLEY	194R-CN30-1753-PY
2	1	LEGEND - AS REQUIRED BY JOB - PLASTIC	PER PRINT/LIST	LEGEND

LEGENDS FOR DOOR LAYOUT							
No.	Qty.	LINE #1	LINE #2	LEGEND SIZE	LETTER SIZE	TAG COLOR	TEXT COLOR
1	1	FD069	.	¾" x 4"	½"	WHITE	BLACK

1 FD069



				LJW HOPPER 1 VENT HOPPER AIRLOCK				 <b>NOL-TEC</b> SYSTEMS www.nol-tec.com Lino Lakes, MN - USA (651) 780-8800 #260	
				FIELD DISCONNECT FD069					
				DESERT VIEW POWER UNIT A & B					
				MECCA, CA					
0	06NOV16	ISSUED FOR CONSTRUCTION		JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15		CATALOG NO.
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 1"=1"		







SHEETS 72-79 ARE RESERVED FOR FUTURE USE


[illegible]






















CP050 PIG REMOTE I/O PANEL  
PRE-WIRED TERMINAL JUNCTION ENCLOSURE



GND   
PRE-WIRED BY NOL-TEC SYSTEMS



						PIG HOPPER		 <b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA www.nol-tec.com (651) 730-8600 ©2007		
						FIELD WIRING				
						DESERT VIEW POWER UNIT A & B				
						MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.	DRAWING NO. 9222A-7-080
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE		










BLOWER/HEAT EXCHANGERS									
FIELD WIRING									
DESERT VIEW POWER UNIT A & B									
MECCA, CA									
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.	DRAWING NO. 9222A-7-081	
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE			





00  
02  
04  
06  
08  
10  
12  
14  
16  
18  
20  
22  
24  
26  
28  
30  
32  
34



LINE 1

LINE 2

DAY BIN

DAY BIN				DAY BIN			
FIELD WIRING				FIELD WIRING			
DESERT VIEW POWER UNIT A & B				DESERT VIEW POWER UNIT A & B			
MECCA, CA				MECCA, CA			
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE	

**NOL-TEC**  
SYSTEMS  
Lino Lakes, MN - USA  
www.nol-tec.com (651) 780-8800  
©2001

DRAWING NO.  
**9222A-7-083**

00

02

04

06

08

10

12

14

16

18

20

22

24













26

28


30


32

34

[illegible]


00  
02  
04  
06  
08  
10  
12  
14  
16  
18  
20  
22  
24  
26  
28  
30  
32  
34



						DAY BIN LINE 2				 <b>NOL-TEC</b> SYSTEMS Lino Lakes, MN - USA www.nol-tec.com (651) 780-8800 ©2001
						FIELD WIRING				
						DESERT VIEW POWER UNIT A & B				
						MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.15	
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE	DRAWING NO. <b>9222A-7-085</b>

SHEETS 86-94 ARE RESERVED FOR FUTURE USE

[illegible]




HOPPER ELEVATION VIEW

				DAY BIN ELEVATION			
				FIELD WIRING			
				DESERT VIEW POWER UNIT A & B			
				MECCA, CA			
0	28JAN16	ISSUED FOR CONSTRUCTION		JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15
REV	DATE	REVISION NOTE		DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE
						CATALOG NO.	DRAWING NO.
							9222A-7-095






00  
02  
04  
06  
08  
10  
12  
14  
16  
18  
20  
22  
24  
26  
28  
30  
32  
34  
36






									DAY BIN ELEVATION	
									FIELD WIRING	
									DESERT VIEW POWER UNIT A & B	
									MECCA, CA	
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.15	CATALOG NO.			
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE NONE				




**NOL-TEC**  
SYSTEMS  
Lino Lakes, MN • USA  
www.nol-tec.com (651) 780-8600  
©2001

DRAWING NO.  
**9222A-7-096**






ENCLOSURE:  
NEMA 4X, 316SS  
HOFFMAN A12106CHNFSS6  
12.00" x 10.00"W x 6.00"D  
SUBPANEL:  
HOFFMAN A12P10  
10.75"H x 8.88"W


						JB100 LIW HOPPER 1 DIFFERENTIAL J-BOX			 <div><b>NOL-TEC</b> SYSTEMS <small>Lino Lakes, MN - USA (651) 780-8600 ©2007</small></div>		
						PANEL & BACKPANEL LAYOUT					
						DESERT VIEW POWER UNIT A & B					
						MECCA, CA					
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.14	CATALOG NO.	DRAWING NO.
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE 3/4"=1"		9222A-7-100







ENCLOSURE:  
NEMA 4X, 316SS  
HOFFMAN A12106CHNFSS6  
12.00" x 10.00"W x 6.00"D  
SUBPANEL:  
HOFFMAN A12P10  
10.75"H x 8.88"W

						JB105 LIW VENT HOPPER 1 DIFFERENTIAL J-BOX		 <b>NOL-TEC</b> SYSTEMS <a href="http://www.nol-tec.com">www.nol-tec.com</a> <small>Lino Lakes, MN - USA (651) 780-8600 ©2007</small>	
						PANEL & BACKPANEL LAYOUT			
						DESERT VIEW POWER UNIT A & B			
						MECCA, CA			
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.14	CATALOG NO.
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 3/4"=1"	
									DRAWING NO.
									9222A-7-105









00  
  
02  
  
04  
  
06  
  
08  
  
10  
  
12  
  
14  
  
16  
  
18  
  
20  
  
22  
  
24  
  
26  
  
28  
  
30  
  
32  
  
34


02625  
□  
TB1  
  
02625  
□  
TB2  
  
02625  
□  
TB3  
  
03414  
□  
TB4  
  
04162  
□  
TB5  
  
04210  
□  
TB6  
  
04212  
□  
TB7  
  
04216  
□  
TB8  
  
04218  
□  
TB9  
  
03414  
□  
TB10  
  
04430  
□  
TB11  
  
SHLD  
□  
TB12

40  
  
42  
  
44  
  
46  
  
48  
  
50  
  
52  
  
54  
  
56  
  
58  
  
60  
  
62  
  
64  
  
66  
  
68  
  
70  
  
72  
  
74

					JB105 LIW VENT HOPPER 1 DIFFERENTIAL J-BOX				 <div><b>NOL-TEC</b> SYSTEMS Lino Lakes, MN • USA www.nol-tec.com (651) 780-8600 ©201</div>		
					WIRING DIAGRAM						
					DESERT VIEW POWER UNIT A & B						
					MECCA, CA						
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.14	CATALOG NO.	DRAWING NO. <b>9222A-7-107</b>
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE		



ENCLOSURE:  
NEMA 4X, 316SS  
HOFFMAN A12106CHNFSS6  
12.00" x 10.00"W x 6.00"D  
SUBPANEL:  
HOFFMAN A12P10  
10.75"H x 8.88"W

						JB110 LIW HOPPER 2 DIFFERENTIAL J-BOX			 <div><b>NOL-TEC</b> SYSTEMS <small>Lino Lakes, MN - USA (651) 780-8600 ©2007</small></div>
						PANEL & BACKPANEL LAYOUT			
						DESERT VIEW POWER UNIT A & B			
						MECCA, CA			
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		
							DATE 06.Aug.14	CATALOG NO.	DRAWING NO. <b>9222A-7-110</b>
							SCALE 3/4"=1"		









00  
  
02  
  
04  
  
06  
  
08  
  
10  
  
12  
  
14  
  
16  
  
18  
  
20  
  
22  
  
24  
  
26  
  
28  
  
30  
  
32  
  
34

02625  
□  
TB1  
  
02625  
□  
TB2  
  
04306  
□  
TB3  
  
04308  
□  
TB4  
  
03414  
□  
TB5  
  
04466  
□  
TB6  
  
SHLD  
□  
TB7  
  
□  
TB8  
  
□  
TB9  
  
□  
TB10  
  
□  
TB11  
  
□  
TB12


40  
  
42  
  
44  
  
46  
  
48  
  
50  
  
52  
  
54  
  
56  
  
58  
  
60  
  
62  
  
64  
  
66  
  
68  
  
70  
  
72  
  
74

						JB110 LIW HOPPER 2 DIFFERENTIAL J-BOX			 <div><b>NOL-TEC</b> SYSTEMS Lino Lakes, MN • USA www.nol-tec.com (651) 780-8800 ©201</div>	
						WIRING DIAGRAM				
						DESERT VIEW POWER UNIT A & B				
						MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.14	CATALOG NO.
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE	
DRAWING NO. 9222A-7-112										

DRAWING NO.  
**9222A-7-112**



ENCLOSURE:  
NEMA 4X, 316SS  
HOFFMAN A12106CHNFSS6  
12.00" x 10.00"W x 6.00"D  
SUBPANEL:  
HOFFMAN A12P10  
10.75"H x 8.88"W

				JB115 LIW VENT HOPPER 2 DIFFERENTIAL J-BOX				 <b>NOL-TEC</b> SYSTEMS www.nol-tec.com <small>Lino Lakes, MN - USA (651) 780-8600 ©2007</small>			
				PANEL & BACKPANEL LAYOUT							
				DESERT VIEW POWER UNIT A & B							
				MECCA, CA							
A	28JAN16	ISSUED FOR CONSTRUCTION				JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.14	CATALOG NO.
REV	DATE	REVISION NOTE				DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 3/4"=1"	DRAWING NO.	
										9222A-7-115	







00  
  
02  
  
04  
  
06  
  
08  
  
10  
  
12  
  
14  
  
16  
  
18  
  
20  
  
22  
  
24  
  
26  
  
28  
  
30  
  
32  
  
34


02625  
□  
TB1  
  
02625  
□  
TB2  
  
02625  
□  
TB3  
  
03414  
□  
TB4  
  
04262  
□  
TB5  
  
04310  
□  
TB6  
  
04312  
□  
TB7  
  
04316  
□  
TB8  
  
04318  
□  
TB9  
  
03414  
□  
TB10  
  
04470  
□  
TB11  
  
SHLD  
□  
TB12

40  
  
42  
  
44  
  
46  
  
48  
  
50  
  
52  
  
54  
  
56  
  
58  
  
60  
  
62  
  
64  
  
66  
  
68  
  
70  
  
72  
  
74

					JB115 LIW VENT HOPPER 2 DIFFERENTIAL J-BOX				 <b>NOL-TEC</b> SYSTEMS Lino Lakes, MN • USA www.nol-tec.com (651) 780-8800 ©2007	
					WIRING DIAGRAM					
					DESERT VIEW POWER UNIT A & B					
					MECCA, CA					
0	28JAN16	ISSUED FOR CONSTRUCTION			JVE	JAB	DRAWN BY J. ELLWEIN		DATE 06.Aug.14	CATALOG NO.
REV	DATE	REVISION NOTE			DRAWN	DESIGN	DESIGN BY J. BROWN		SCALE NONE	
DRAWING NO. 9222A-7-117										

DRAWING NO.  
9222A-7-117



			JB120 SILO AIR PAD DISTRIBUTOR J-BOX			 <b>NOL-TEC</b> SYSTEMS www.nol-tec.com Line Lakes, MN - USA (651) 780-8600 ©2007	
			PANEL & BACKPANEL LAYOUT				
			DESERT VIEW POWER UNIT A & B				
			MECCA, CA				
0	28JAN16	ISSUED FOR CONSTRUCTION	JVE	JAB	DRAWN BY J. ELLWEIN	DATE 06.Aug.14	CATALOG NO.
REV	DATE	REVISION NOTE	DRAWN	DESIGN	DESIGN BY J. BROWN	SCALE 3/4"=1"	DRAWING NO.
						9222A-7-120	







**Operation & Maintenance Manual**  
*Desert View Power LLC, Greenleaf Power*  
*Hydrated Lime DSI System*  
MECCA, CA  
Nol-Tec Contract Numbers: 4723  
Nol-Tec Systems Site Numbers: 9222A

## **Section A4. Spare Parts List**

---

**Revision Date**

### A4.1 Recommended Spare Parts List



## RECOMMENDED SPARE PARTS

*Nol-Tec Systems welcomes the opportunity to provide you with your spare parts needs. Please utilize this form as a Request for Quotation. Simply identify the items you need, and a quote will be provided within 24 hours.*

February 25, 2016

Customer **DESERT VIEW POWER COMPANY**

Location **MECCA, CA**

Job Number **4723 / 9222A**

Mech. Eng **MICHAEL BOSIO**

Elec. Eng **AL HEUER**

Proj. Mgr. **TIM KAUTZ**

### Spare Parts Contact

*Dennis Iverson*

Spare Parts Coordinator

**Phone: 651-780-8600 x 243**

**Fax: 651-780-4400**

**E-mail: dennisiverson@nol-tec.com**

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
36177	ACTUATOR, BUTTERFLY, 10" & 12" VALVES W/ INTERNAL TRAVEL STOPS, & BRACKET	65260 VALVE, BUTTERFLY, 12", SERIES 31, ASEM	1	1
38060	REPAIR KIT, ACTUATOR, SERIES 92, 10"&12"	36177 ACTUATOR, BUTTERFLY, 10" & 12" VALVES W/ INTERNAL TRAVEL STOPS, & BRACKET	KIT	1
35089	ACTUATOR, BUTTERFLY, 3" & 4" VALVES W/ INTERNAL TRAVEL STOPS	41291 VALVE, BUTTERFLY, 3", SERIES 30, ASEM	2	1
36747	REPAIR KIT, ACTUATOR, SERIES 92, 3" & 4"	35089 ACTUATOR, BUTTERFLY, 3" & 4" VALVES W/ INTERNAL TRAVEL STOPS	KIT	1
35069	ACTUATOR, BUTTERFLY, 5" VALVE W/ INTERNAL TRAVEL STOPS	67420 VALVE, BUTTERFLY, 5", SERIES 30, ASEM	1	1
38592	REPAIR KIT, ACTUATOR SERIES 92, FOR 5"	35069 ACTUATOR, BUTTERFLY, 5" VALVE W/ INTERNAL TRAVEL STOPS	KIT	1

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
67733	ACTUATOR, BUTTERFLY, 8" VALVE W/ EXTENDED TRAVEL STOPS	67734 VALVE, BUTTERFLY, 8", SERIES 30, ASEM	4	1
37370	REPAIR KIT, ACTUATOR, SERIES 92, 8" REPAIR KIT, ACTUATOR, SERIES 92, 8"	67733 ACTUATOR, BUTTERFLY, 8" VALVE W/ EXTENDED TRAVEL STOPS	KIT	1
67716	ADAPTER, CAM & GROOVE, TYPE A, 5" ALUM	67664 TRAILER, PNEUMATIC DRY BULK TANK	1	1
67533	ADAPTER, FLGD, 1-1/2" SCH 40 X 6" LG, MS WITH 1/2" COUPLING,	67431 GRAVITY SPLITTER, ASEM	8	1
27400	AERATOR VALVE, CLEAR, ASEM CLEAR URTH, CER SEAT, CI MAN, 2" DIA CYL	50848 FLUIDIZING BIN BTM, 12" OUTLET, MS, ASE	3	1
67617	AIR CONDITIONER, 2000 BTUH, 480V/.93 AMP W/ MALFUNCTION SWITCH	67623 CONTROL ENCLOSURE (CP030)	1	1
67616	AIR CONDITIONER, 6000 BTUH, 480V/1.8 AMP W/ MALFUNCTION SWITCH, RAZOR SERIES	67603 CONTROL ENCLOSURE (CP020)	1	1
10978	ARM, LIMIT SWITCH	48384 BRACKET, LIMIT SWITCH, 4", MS, ASEM	1	1
35784	BEND, 3" SCH 40, 90 DEG, MS 24" CLR, 6" TAN & 6" TAN	SHIPPED LOOSE	10	1
63861	BEND, TEE, 4" TO 6" SCH 40, MS, FAB (1) END CAP 90 DEG, 8" TO 6" REDUC	SHIPPED LOOSE	1	1
67372	BRACKET, SUPPORT FOR 4" & 5" PIPE, MS, DAY BIN SUPPORT	SHIPPED LOOSE	1	1
10151	CLAMP, QUICK RELEASE, 301SS NOL-TEC	SHIPPED LOOSE	29	2
67611	CONDUCTOR, ALUM., 7/16" DIA, 50'-0" COIL CLASS I LIGHTNING PROTECTION	67613 LIGHTNING PROTECTION, ASEM, DAY BIN	1	1
67380	CONNECTOR, FLEX 4 1/4" ID X 6 1/4" ID 5" LG RCN OUTER, W/ 5"LG .020 THK LINER	67031 FRAME, LOWER, DAY BIN, ASEM	2	1

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
67381	CONNECTOR, FLEX 4 3/4" ID X 6 5/8" ID 5" LG RCN OUTER, W/ 5"LG .020 THK LINER	SHIPPED LOOSE	2	1
18741	COUPLING, STYLE 99, 1-1/2"	SHIPPED LOOSE	32	2
10210	COUPLING, STYLE 99, 3"	SHIPPED LOOSE	40	1
15320	GASKET, 3", STYLE 99, CPLG, EPDM	10210 COUPLING, STYLE 99, 3"	KIT	2
10211	COUPLING, STYLE 99, 4"	SHIPPED LOOSE	15	NOT RECOMMENDED
15321	GASKET, 4", STYLE 99, CPLG, EPDM	10211 COUPLING, STYLE 99, 4"	KIT	1
11355	COUPLING, STYLE 99, 5"	SHIPPED LOOSE	15	NOT RECOMMENDED
15023	GASKET, 5", STYLE 99, CPLG, EPDM	11355 COUPLING, STYLE 99, 5"	KIT	1
67984	DISCONNECT SWITCH, ENCLOSED, 60 A, NEMA 4X, NON-FUSED, STAINLESS	67985 ENCLOSURE, FIELD DISCONNECT, 60 AMP	3	1
67985	ENCLOSURE, FIELD DISCONNECT, 60 AMP, NOL-TEC	SHIPPED LOOSE	3	1
68028	ETHERNET CONFIGURABLE ROUTER, 3 PORT NETWORK ADDRESS TRANSLATION	67623 CONTROL ENCLOSURE (CP030)	1	1
55211	EXHAUST FAN, WALL MOUNT, 18" DIA, 1/3 HP, 1725 RPM, 115/230V, GALV, 22"	67027 FRAME, UPPER, DAY BIN	1	NOT RECOMMENDED
21DV21	PROPELLER	55211 EXHAUST FAN, WALL MOUNT, 18" DIA, 1/3 HP, 1725 RPM, 115/230V, GALV, 22"		1
21DV44	MOTOR	55211 EXHAUST FAN, WALL MOUNT, 18" DIA, 1/3 HP, 1725 RPM, 115/230V, GALV, 22"		1

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
20515	EXHAUSTER, PB14A, 1100 CFM, 3HP, 6" SP, 8" INLET, CCW BH, ARR4, 230/460V	SHIPPED LOOSE	1	NOT RECOMMENDED
WHEEL	12.25 X 2-7/8 ALUM, 1-1/8 BR WHEEL	20515 EXHAUSTER, PB14A, 1100 CFM, 3HP, 6" SP, 8" INLET, CCW BH, ARR4, 230/460V		1
MOTOR	MTR, 3 HP, 3450RPM, 3PH, 60HZ, 230/460V, TEFC, EPACT, EFF, FM, 182T, 1.15 SF, F INSUL., 40C AMB, F1 BOX, STEEL FRAME	20515 EXHAUSTER, PB14A, 1100 CFM, 3HP, 6" SP, 8" INLET, CCW BH, ARR4, 230/460V		1
67038	FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC	67036 FEEDER 01, LIW, ASEM 67037 FEEDER 02, LIW, ASEM	2	NOT RECOMMENDED
10891901	SPROCKET, SYNC MS	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
108920	BUSHING	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
108927	BELT	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
21146700	MOD, SPKT	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
20388805	ASSY, HEAVY DUTY ROD END BEARING	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
002065	BEARING, ROD, END ROLLER	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		3
20181505	CAM, AGITATOR DRIVE	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
21097406	THR ROD, SS 3/8 -24 X 10	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
002061	BEARING, FLANGE, 2 BOLT	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		4
21118011	FEEDTUBE	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
21108223027. 5	AUGER	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
108929	MOTOR, 1/2 HP	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
004404	REDUCER	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
002625	HOPPER, FLEX 12 SER, INDUSTRIAL GRADE	67038 FEEDER, V-12, 1.75" DIA, 12.375" F-C, DUAL DRIVE, NO EXT HOPPER, 480VAC		1
21938	FILTER, 1", 5 MICRON	67712 CONTROLS, AIR, TRAILER,	1	1
59621	FILTER, 1/2" NPT, 5 MICRON ELEMENT	67149 AIR CONTROL, BIN BOTTOM AND DUAL 67532 AIR CONTROL, SPLITTER, (4) LANCES, ASEM	3	1
32533	FILTER, CARTRIDGE, BTM RMVL, 30 SQ FT 36", SB SPUN BOND POLY, 42.6"OAL,	SHIPPED LOOSE	25	25
40228	FILTER, CARTRIDGE, TOP RMVL, 10 SQ FT 18.4" LG , SPUN BOND POLY	67186 SGL CART DUST FILTER, 10 SQ FT, MS, ASE	8	2
62517	FILTER, REGULATOR, 3/8", 0-60 PSIG	67082 AIR CONTROL, SGL CART DUST FILTER 67111 AIR CONTROL, SGL CART DUST FILTER	4	1
44216	FLOW METER, W/ NO VALVE, 10-100 SCFH, 100 PSIG MAX, 1/8" NPT	67082 AIR CONTROL, SGL CART DUST FILTER 67111 AIR CONTROL, SGL CART DUST FILTER	8	1
28737	FUSE HOLDER, 1 POLE, 600V, 30 AMP WITH BLOWN FUSE INDICATOR	67148 JUNCTION ENCLOSURE, SILO DISCHARGE	1	1
36777	FUSE, 600 V, 5 AMP, CLASS CC TIME DELAY	67148 JUNCTION ENCLOSURE, SILO DISCHARGE	1	1
10383	GASKET, DUST FILTER DOOR, 1/4" X 2" WD, PORON	67333 DUST COLLECTOR, 60NT25, MS, ASEM	12	12
16541	GASKET, FULL FACE, 6", 150 LB, 1/8" THK RED RUBBER	67027 FRAME, UPPER, DAY BIN	2	1

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
10390	GASKET, RED RUBBER RING, 6", 150 LB 1/8" THK	67431 GRAVITY SPLITTER, ASEM	4	1
28819	GASKET, SGL CARTRIDGE DUST FILTER NOL-TEC	67031 FRAME, LOWER, DAY BIN, ASEM	8	2
11527	GAUGE, 2-1/2", 1/4" NPT, 0-100 PSI, GLYC, BOTTOM MNT, POLYCARBONATE, SS	67149 AIR CONTROL, BIN BOTTOM AND DUAL	3	1
11528	GAUGE, 2-1/2", 1/4" NPT, 0-160 PSI, GLYC, BOTTOM MNT, POLYCARBONATE	67031 FRAME, LOWER, DAY BIN, ASEM 67772 AIR SUPPLY, TOP OF DAY BIN, ASEM	2	1
38756	GAUGE, 2-1/2", 1/4" NPT, 30" HG, 0-30 PSIBTM MTG, SS CASE, POLY LENSE, GLYC	67532 AIR CONTROL, SPLITTER, (4) LANCES, ASEM	8	1
67539	GRAVITY SPLITTER SUPPORT STAND, MS, FAB NOL-TEC	67431 GRAVITY SPLITTER, ASEM	2	1
67453	GRAVITY SPLITTER, MS, FAB, 3" SCH 40 INLET, (4) 1-1/2" SCH 40 OUTLETS	67431 GRAVITY SPLITTER, ASEM	2	1
67203	GUARD, EXHAUST FAN, FOR USE W/ DAYTON 18" FAN, #10D985	67027 FRAME, UPPER, DAY BIN	1	1
67590	HEAT EXCHANGER, AIR COOLED, 1HP, 3" IN & OUT, INSTRUMENT COUPLING, 279 F TO 132	SHIPPED LOOSE		NOT RECOMMENDED
52225*	MOTOR	67590 HEAT EXCHANGER, AIR COOLED, 1HP, 3" IN & OUT, INSTRUMENT COUPLING, 279 F TO 132		1
42310*	FAN	67590 HEAT EXCHANGER, AIR COOLED, 1HP, 3" IN & OUT, INSTRUMENT COUPLING, 279 F TO 132		1
47717*	VENTURI FRAME	67590 HEAT EXCHANGER, AIR COOLED, 1HP, 3" IN & OUT, INSTRUMENT COUPLING, 279 F TO 132		1
22409E	EXHAUST HOOD	67590 HEAT EXCHANGER, AIR COOLED, 1HP, 3" IN & OUT, INSTRUMENT COUPLING, 279 F TO 132		1
48983*	FAN GUARD	67590 HEAT EXCHANGER, AIR COOLED, 1HP, 3" IN & OUT, INSTRUMENT COUPLING, 279 F TO 132		1

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
10415	HOSE ASEM, 1"M X 1"MS, 24", STD NOL-TEC	67115 FLUIDIZING BIN BOTTOM & DUAL OUTLET	1	1
10417	HOSE ASEM, 1"M X 1"MS, 36", STD NOL-TEC	67031 FRAME, LOWER, DAY BIN, ASEM 67116 AIR DISTRIBUTOR ASSEMBLY	2	1
10419	HOSE ASEM, 1/2"M X 1/2"MS, 24", STD NOL-TEC	67031 FRAME, LOWER, DAY BIN, ASEM	4	1
60537	HOSE ASEM, 1/2"M X 1/2"MS, 30", STD NOL-TEC	67031 FRAME, LOWER, DAY BIN, ASEM	4	1
10420	HOSE ASEM, 1/2"M X 1/2"MS, 40", STD NOL-TEC	67031 FRAME, LOWER, DAY BIN, ASEM	4	1
11564	HOSE ASEM, 1-1/2"M X 1-1/2"MS, 24", STD NOL-TEC	67031 FRAME, LOWER, DAY BIN, ASEM	2	1
66411	HOSE ASEM, 1-1/2"M X 1-1/2"MS, 84", STD NOL-TEC	67031 FRAME, LOWER, DAY BIN, ASEM	1	1
40172	HOSE ASEM, 3/4"M X 3/4"MS, 40", STD NOL-TEC	41499 FLUIDIZING BIN BOTTOM, MECH SUBSTRUCTUR	3	1
67715	HOSE, 3" X 10'-0", MATERIAL HANDLING, 690SB, INT EXPANDED PLAIN END X INT	SHIPPED LOOSE	1	1
67427	HOSE, 3" X 7'-0", MATERIAL HANDLING, 690SB, PLAIN ENDS, INT EXPANDED	SHIPPED LOOSE	2	1
67598	HOSE, 4" X 10'-0", MATERIAL HANDLING, 690SB, INT EXPANDED PLAIN END X INT	SHIPPED LOOSE	1	1
67602	HOSE, 5" X 10'-0", MATERIAL HANDLING, 690SB, INT EXPANDED PLAIN END X INT	SHIPPED LOOSE	1	1
67649	HOUSING, DAMPER, 6-3/4" I.D., MS NOL-TEC	67648 DAMPER, BACK DRAFT, 6" PIPE FIT, MS	1	1
42138	LEVEL CONTROL, 12", ASEM PROXIMITY 24V/120V/220VAC	67027 FRAME, UPPER, DAY BIN 67664 TRAILER, PNEUMATIC DRY BULK TANK	5	1



Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
40954	LEVEL CONTROL, 19", PROXIMITY VOLTAGE 24 VDC/ 120 VAC/ 220 VAC	42138 LEVEL CONTROL, 12", ASEM 43595 LEVEL CONTROL, 36", ASEM 44539 LEVEL CONTROL, 24", ASEM	9	1
44539	LEVEL CONTROL, 24", ASEM PROXIMITY 24V/120V/220V	67027 FRAME, UPPER, DAY BIN 67664 TRAILER, PNEUMATIC DRY BULK TANK	3	1
43595	LEVEL CONTROL, 36", ASEM PROXIMITY 24V/120V/220V	67027 FRAME, UPPER, DAY BIN	1	1
67405	LIFTING LUG, LOWER HOPPER FRAME, MS, BOLT CONNECTION	67031 FRAME, LOWER, DAY BIN, ASEM	4	1
67363	LIGHT, LED, 3K L, 120-277 VAC, 50/60HZ, 41W, 1" WALL MOUNT,	SHIPPED LOOSE	4	1
67430	LIGHT, LED, 3K L, 120-277 VAC, 50/60HZ, 41W, 1-1/2" STANCHION STRAIGHT MOUNT,	SHIPPED LOOSE	1	1
22447	LIMIT SWITCH	48384 BRACKET, LIMIT SWITCH, 4", MS, ASEM	1	1
19820	LIMIT SWITCH, 3 INLET PORTS, DBL NAMUR MOUNT	41291 VALVE, BUTTERFLY, 3", SERIES 30, ASEM 65260 VALVE, BUTTERFLY, 12", SERIES 31, ASEM 67420 VALVE, BUTTERFLY, 5", SERIES 30, ASEM 67734 VALVE, BUTTERFLY, 8", SERIES 30, ASEM	8	1
61436	MEMBRANE, BOTTOM AERATION, 12" RING GASKET, URETHANE, MINI-JET, HABASIT,	67116 AIR DISTRIBUTOR ASSEMBLY	1	1
67395	MOUNTING PLATE, FEEDER FRAME, MS NOL-TEC	67036 FEEDER 01, LIW, ASEM 67037 FEEDER 02, LIW, ASEM	4	1
67563	NOZZLE, 1-1/2" LANCE INJECTOR, MS, (1) LANCE, 4" 150 LB MTG, 50" LG	SHIPPED LOOSE	4	1
67564	NOZZLE, 1-1/2" LANCE INJECTOR, MS, (1) LANCE, 4" 150 LB MTG, 75" LG	SHIPPED LOOSE	4	1
32481	O-RING, 1/2" ID X 1/8 C/S 70 DURO, BLK COMPOUND #9746, VITON ACID	67375 CONTROL ENCLOSURE, DC, 5-BANK, 24 VDC	2	1

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
47218	O-RING, 4" INLINE SCREENER, 3/8 CS, 9.69" ID, 10.07" OD, 60-70A BUNA-N, BONDED	67708 SCREENER, INLINE, 4", HINGED, O-RING, ASE	2	2
50930	PLATE, SCREENING, 3/8" THK, MS WIRE CLOTH, 1/4" DIA ROD, FOR 4" SCREEN	67708 SCREENER, INLINE, 4", HINGED, O-RING, ASE	1	1
67714	REDUCER, 6" TO 5" CONCENTRIC, MS, NPT ON BOTH ENDS,	67664 TRAILER, PNEUMATIC DRY BULK TANK	1	1
14318	REGULATOR, 1" NPT	67149 AIR CONTROL, BIN BOTTOM AND DUAL 67772 AIR SUPPLY, TOP OF DAY BIN, ASEM	3	1
16968	REPAIR KIT, 1" & 3/4" REGULATORS	14318 REGULATOR, 1" NPT	KIT	1
14204	REGULATOR, 1/2" NPT	67049 AIR CONTROL, SGL CART DUST FILTER, ASEM 67055 AIR CONTROL, SGL CART DUST FILTER, ASEM 67082 AIR CONTROL, SGL CART DUST FILTER 67111 AIR CONTROL, SGL CART DUST FILTER	4	1
42442	RELAY, TERMINAL BLOCK, SPDT, 120 VAC & 125 VDC, SLIM LINE, BUILT IN LINE LEAK	67375 CONTROL ENCLOSURE, DC, 5-BANK, 24 VDC	1	1
67032	ROTARY AIRLOCK, 8" SQ, 8 VANE, HDX, MS 3/4HP, 15 RPM, 460V-60-30 TEFC, CUT/BEV	67034 VENT HOPPER 01, ASEM, 5" INLET 67035 VENT HOPPER 02, ASEM, 5" INLET	2	NOT RECOMMENDED
430C-552NS	ROTOR	67032 ROTARY AIRLOCK, 8" SQ, 8 VANE, HDX, MS 3/4HP, 15 RPM, 460V-60-30 TEFC, CUT/BEV		1
59302	CAP, DRIVE END BEARING	67032 ROTARY AIRLOCK, 8" SQ, 8 VANE, HDX, MS 3/4HP, 15 RPM, 460V-60-30 TEFC, CUT/BEV		1
59304	NUT, PACKING GLAND	67032 ROTARY AIRLOCK, 8" SQ, 8 VANE, HDX, MS 3/4HP, 15 RPM, 460V-60-30 TEFC, CUT/BEV		2
8X8HDX-KIT02	SEAL BEARING KIT WITH LANTERN RING	67032 ROTARY AIRLOCK, 8" SQ, 8 VANE, HDX, MS 3/4HP, 15 RPM, 460V-60-30 TEFC, CUT/BEV		1
61500	SCALE, BENCH, 1,000#, 18 X 24 X 5.25 SINGLE POINT, RL1260 LOAD CELL	SHIPPED LOOSE	2	NOT RECOMMENDED

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
19095*	TOP COVER	61500 SCALE, BENCH, 1,000#, 18 X 24 X 5.25 SINGLE POINT, RL1260 LOAD CELL		1
19141*	FOOT	61500 SCALE, BENCH, 1,000#, 18 X 24 X 5.25 SINGLE POINT, RL1260 LOAD CELL		1
91683*	LOAD CELL	61500 SCALE, BENCH, 1,000#, 18 X 24 X 5.25 SINGLE POINT, RL1260 LOAD CELL		1
67407	SHIPPING SUPPORT, FLUIDIZING BIN BOTOM, LOWER FRAME BOLT CONNECTION	67031 FRAME, LOWER, DAY BIN, ASEM	2	1
50783	SURGE SUPPRESSOR, 120 VAC, 20 AMP, DUPLEX OUTLET INCLUDED	67603 CONTROL ENCLOSURE (CP020)	1	1
45270	THERMOSTAT, SPST, 30-110 DEG F 3-1/2 DEG F DIFF, SS ELEMENTS	67027 FRAME, UPPER, DAY BIN	1	1
67408	THUMB SCREW, WING HEAD, 3/8"-16 X 1", MS, ZINC-PLATED	67031 FRAME, LOWER, DAY BIN, ASEM	80	5
46172	TIMER, 1-10 BANK, 10-35 VDC 50-500 MSEC ON TIME, 1-180 SEC OFF	67375 CONTROL ENCLOSURE, DC, 5-BANK, 24 VDC	1	1
28974	TRANSMITTER, PRESSURE, -15 TO +15 PSIG 4-20MA, 1/2 CONDUIT, 1/2" MNPT/1/4"FNPT	67532 AIR CONTROL, SPLITTER, (4) LANCES, ASEM SHIPPED LOOSE	11	1
37252	TRANSMITTER, PRESSURE, W/ MAG GAUGE RANGE 0-10.0 IN WC, 4-20MA OUTPUT PANEL	67097 JUNCTION BOX, SGL CART DUST FILTER, ASE 67375 CONTROL ENCLOSURE, DC, 5-BANK, 24 VDC	5	1
55864	TRANSMITTER, TEMP, RTD, 1/2 NPT, 0-400 FPYROMATION 4" INSERT, 2-WIRE	SHIPPED LOOSE	5	1
48508	VALVE, BALL,1-1/2",MANUAL,FULL PORT,CS MODEL F15, FLANGED, 2-PIECE	67431 GRAVITY SPLITTER, ASEM	8	1
40823	VALVE, BUTTERFLY, 12", 118 TRIM, SERIES 31	44950 VALVE, BUTTERFLY, 12" SERIES 31, ASEM 65260 VALVE, BUTTERFLY, 12", SERIES 31, ASEM	2	1
24228	REPAIR KIT 12" BUTTERFLY VALVE	40823 VALVE, BUTTERFLY, 12", 118 TRIM, SERIES 31	KIT	1

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
22924	VALVE, BUTTERFLY, 3", 118 TRIM, SERIES 30	24165 VALVE, BUTTERFLY, 3", SERIES 30, ASEM 41291 VALVE, BUTTERFLY, 3", SERIES 30, ASEM	4	1
24233	REPAIR KIT, 3" SER 20/30, EPDM SEAT	22924 VALVE, BUTTERFLY, 3", 118 TRIM, SERIES 30	KIT	1
31905	VALVE, BUTTERFLY, 5", 118 TRIM, SERIES 30	67420 VALVE, BUTTERFLY, 5", SERIES 30, ASEM	1	1
31850	REPAIR KIT, 5 SERIES 20/30, EPDM SEAT	31905 VALVE, BUTTERFLY, 5", 118 TRIM, SERIES 30	KIT	1
23248	VALVE, BUTTERFLY, 8", 118 TRIM, SERIES 30	67734 VALVE, BUTTERFLY, 8", SERIES 30, ASEM	4	1
24230	REPAIR KIT, 8" SER 20/30, EPDM SEAT	23248 VALVE, BUTTERFLY, 8", 118 TRIM, SERIES 30	KIT	1
58740	VALVE, DIAPHRAGM 3/4" BUNA NITRILE SEALSCOMPRESSION FITTING, SERIES 4,	67333 DUST COLLECTOR, 60NT25, MS, ASEM	5	1
58748	DIAPHRAGM REPLACEMENT KIT, 3/4" SHOCKWAVE DIAPHRAGM	58740 VALVE, DIAPHRAGM 3/4" BUNA NITRILE SEALSCOMPRESSION FITTING, SERIES 4,	KIT	1
58793	VALVE, DIAPHRAGM 3/4", THREADED SERIES 4	67186 SGL CART DUST FILTER, 10 SQ FT, MS, ASE	8	1
58748	DIAPHRAGM REPLACEMENT KIT, 3/4" SHOCKWAVE DIAPHRAGM	58793 VALVE, DIAPHRAGM 3/4", THREADED SERIES 4	KIT	1
10915	VALVE, NEEDLE, 1/2" ARO	67532 AIR CONTROL, SPLITTER, (4) LANCES, ASEM	8	1
10917	VALVE, NEEDLE, 1/4" ARO	67772 AIR SUPPLY, TOP OF DAY BIN, ASEM,	1	1
10919	VALVE, NEEDLE, 3/8" ARO	67034 VENT HOPPER 01, ASEM, 5" INLET 67035 VENT HOPPER 02, ASEM, 5" INLET 67037 FEEDER 02, LIW, ASEM 67082 AIR CONTROL, SGL CART DUST FILTER 67111 AIR CONTROL, SGL CART DUST FILTER	12	1

Part Number	Description	Used On Catalogue No / Description	Qty Used	Qty Rec'm
62689	VALVE, RELIEF, 1" X 1-1/4" @ 15 PSI AIR-SERVICE	67149 AIR CONTROL, BIN BOTTOM AND DUAL	1	1
45335	VALVE, SOLENOID, 1"- 2 WAY, 24VDC, NC, W/ MANUAL OVERRIDE	67149 AIR CONTROL, BIN BOTTOM AND DUAL	1	1
27916	VALVE, SOLENOID, 1/4", SGL, 24VDC, 6W, NAMUR MOUNT, SQ CONN & 6' MOLDED CORD	41291 VALVE, BUTTERFLY, 3", SERIES 30, ASEM 65260 VALVE, BUTTERFLY, 12", SERIES 31, ASEM 67420 VALVE, BUTTERFLY, 5", SERIES 30, ASEM 67734 VALVE, BUTTERFLY, 8", SERIES 30, ASEM	8	1
29569	VALVE, SOLENOID, 1/4", SGL, 24VDC	41499 FLUIDIZING BIN BOTTOM, MECH SUBSTRUCTUR	1	1
18919	REPAIR KIT, VALVE, SOLENOID, SINGLE, SPOOL & O-RINGS, WITH PME-1 PILOT VLV	29569 VALVE, SOLENOID, 1/4", SGL, 24VDC	KIT	1
28236	VALVE, SOLENOID, 1/8", 2-WAY, PILOT, PANEL MOUNTED	67097 JUNCTION BOX, SGL CART DUST FILTER, ASE 67375 CONTROL ENCLOSURE, DC, 5-BANK, 24 VDC	13	1
67732	VALVE, SOLENOID, 2", 24V, 2-WAY, NEMA4 ASCO	67664 TRAILER, PNEUMATIC DRY BULK TANK	4	1
45336	VALVE, SOLENOID, 3/8" - 2 WAY, 24VDC, W/MANUAL OVERRIDE	67082 AIR CONTROL, SGL CART DUST FILTER 67111 AIR CONTROL, SGL CART DUST FILTER	4	1
50776	WEIGH SCALE CONTROLLER, PANEL MOUNT 24 VDC, AB TCP-IP, ROC INCLUDED	67623 CONTROL ENCLOSURE (CP030)	2	1

**Operation & Maintenance Manual**  
*Desert View Power LLC, Greenleaf Power*  
*Hydrated Lime DSI System*  
MECCA, CA  
Nol-Tec Contract Numbers: 4723  
Nol-Tec Systems Site Numbers: 9222A

## **Section A5. Engineering Information & Lists**

---

**Revision Date**

- A5.1 Operational Description
- A5.2 Air Settings Sheet

**Operation & Maintenance Manual**  
*Desert View Power LLC, Greenleaf Power*  
*Hydrated Lime DSI System*  
MECCA, CA  
Nol-Tec Contract Numbers: 4723  
Nol-Tec Systems Site Numbers: 9222A

<b>Section A6. Nol-Tec Systems Standard Manuals</b>	<b>Revision Date</b>
---	----------------------

---

- |      |  |
|------|--|
| A6.1 | System Installation Manual                                     |
| A6.2 | Instructions for Storage of Nol-Tec Equipment                  |
| A6.3 | Maintenance Schedule   |
| A6.4 | Pneumatic Conveying System Operating & Trouble Shooting Manual |



# SYSTEM INSTALLATION MANUAL



**[www.nol-tec.com](http://www.nol-tec.com)**

425 Apollo Drive • Lino Lakes, MN 55014  
Telephone US 651-780-8600  
©Feb 2005



## IMPORTANT NOTICE

Failure to properly install, maintain and operate your Nol-Tec system or components may result in property damage, as well as serious bodily injury.

Failure to properly install, maintain and operate your Nol-Tec system or components may void any and all warranties of the manufacturer's workmanship and designs.

If you are not qualified, trained and authorized to perform installation, maintenance or operation of the system or components, please report to your supervisor and obtain their direction in these regards.

## CONSULTATION AND KEEPING OF THIS MANUAL

1. This manual is intended for the User of the equipment manufactured by NOL-TEC SYSTEMS INC., Lino Lakes, MN, USA. It must be read by the operator and the workman installing and maintaining this equipment.
2. This manual describes general use limits and includes technical specifications for installation, maintenance, trouble shooting and parts list. It also includes information on safety devices and instructions about the User safety.
3. This manual is an integral part of the equipment and must be kept for reference.
4. The manual should be kept in a safe place.
5. The User can suggest changes to improve this manual to the Manufacturer or his Agent. Suggestions will be appreciated and reviewed to determine merit.
6. The Manufacturer disclaims responsibility in case of:
  - a) Improper use of equipment.
  - b) Use not in compliance with specific laws even if these are subsequent to the sale date of this equipment.
  - c) Incorrect installation.
  - d) Feed damages.
  - e) Serious failure in the expected maintenance.
  - f) Unauthorized modifications to the equipment.
  - g) Removing or deleting the security devices and signals.
  - h) Use of parts manufactured by other than the original manufacturer.
  - i) Total or partial non-observance of the instructions supplied in this manual.
  - j) Exceptional or unpredictable events.
  - k) Improper use of the equipment with materials or in situations not expressly authorized by the Manufacturer.
7. Before moving, installing or using the equipment, carefully read this manual.
8. It is necessary to evaluate carefully the possibility of using this equipment with inflammable, corrosive, explosive materials, or material for which particular precautions are prescribed.

# TABLE OF CONTENTS

INTRODUCTION.....	4
RECEIVING EQUIPMENT .....	4
UNLOADING EQUIPMENT .....	4
INVENTORY OF EQUIPMENT .....	4
STORAGE OF EQUIPMENT .....	4
PAINTING .....	4
USE OF DRAWINGS.....	5
CODES AND STANDARDS.....	6
INSTALLATION PROCEDURE .....	7
AIR PIPING .....	8
INSPECTION AND START-UP .....	8
START-UP CHECK LIST .....	9
FIELD MODIFICATIONS.....	9
COMPONENT INSTALLATION .....	9

## INTRODUCTION

This manual provides you with a comprehensive guide to the installation of your Nol-Tec material handling system. We recommend you carefully study its contents. The performance of your system is reflected by how well you install and maintain the equipment.

### RECEIVING EQUIPMENT

The equipment shipped to you by Nol-Tec has been loaded with care to prevent any damage during shipment. From time to time, the carrier will off-load and reload a shipment. When this happens, there is a strong possibility the equipment may be improperly reloaded.

Because of this, Nol-Tec suggests a thorough inspection for visible external damage of all containers, pallet boxes, and large parts (such as transporters, dust collectors, hoppers, chutes and pipe). If any damage is obvious or questionable, a thorough inspection and immediate claim must be made against the carrying truck line.

A check of the number of pieces received compared to the number of pieces indicated on the Bill of Lading must be performed. Nol-Tec has found this necessary, due to trucking firm's common practice of off-loading and reloading at various terminals. Your right to claim damages or shortages is waived upon signing the Bill of Lading.

Nol-Tec cannot take responsibility for any equipment damaged in transit. If you feel any item is questionable, please contact Nol-Tec's Shipping Department at once for assistance.

### UNLOADING OF EQUIPMENT

The unloading of equipment, which is the responsibility of the customer or his selected contractor, must be performed with care. This phase of the installation is critical to ensure all equipment is installed in an undamaged state. Nol-Tec cannot take responsibility for damage to equipment during unloading.

All trucks will be loaded in such a way to facilitate existing conditions and unloading equipment availability at the job site; provided the customer or contractor makes Nol-Tec aware of these conditions.

### INVENTORY OF EQUIPMENT

Due to the nature of the equipment provided by Nol-Tec, and the methods and work forces necessary to install Nol-Tec systems, we suggest a complete inventory of all items be performed.

This inventory will assure the customer or contractor that all items on the packing list have been received in an undamaged condition, and will aid in your familiarization with the equipment. Any discrepancies in the quality, description of items received, and/or the actual count of pieces must be reported to the Nol-Tec Shipping Department immediately.

### STORAGE OF EQUIPMENT

After the receiving, unloading, and inventorying of your shipment, special consideration must be given to the storage of the equipment. All equipment shipped from Nol-Tec is for immediate installation and start-up. No provisions have been made for extended storage or storage in an area which is unsuitable for mechanical equipment.

Many of the pieces of equipment have working surfaces that may corrode if not given special attention. Consequently, warranties and guarantees cannot be honored when it is apparent that good storage procedures have not been exercised prior to installation.

If any questions should arise regarding storage or extended storage, please contact the Nol-Tec Mechanical Engineering department.

### PAINTING

Standard Nol-Tec components are provided with one coat of Nol-Tec standard silicone modified alkyd paint with a gloss finish. Tubing, however, is provided unpainted.

Due to the nature of the equipment and the construction techniques required for its installation, you will find painting of the equipment best performed after installation. Care should be taken not to paint any moving parts or sliding surfaces.

Depending on special conditions, painting may not be considered necessary. Nol-Tec advises this be done to ensure maximum life of the system.

## USE OF DRAWINGS

Drawings have been provided for proper installation and operation and must be followed closely. Any changes in layout and/or design must be reported to and changes documented and approved by the Nol-Tec Engineering Departments.

NOTE: Installation supervision is recommended and available upon request to insure safe and efficient operation. Contact the Nol-Tec Service Department for details.

A brief explanation of Nol-Tec drawing numbers follows:

- 1) The letter preceding the drawing number signifies the physical size of the drawing.

- [A] 8½" x 11"
- [B] 11" x 17"
- [C] 18" x 24"
- [D] 24" x 36"

- 2) The first set of numbers may be either 3 or 4-digits. Three-digit numbers are standard Nol-Tec drawings. Four-digit numbers are for a specific customer, at a specific location. This 4-digit number is your Nol-Tec job number.
- 3) The letter(s) suffixing the job number is the system designation, representing the specific system the drawing was prepared for.
- 4) The next digit represents a particular type of drawing for a system.

- [1] General Arrangement
- [2] Installation Detail
- [3] Piping Diagram
- [4] Electrical Control Assembly
- [5] System Bill of Material
- [6] Electrical Schematic
- [7] I/O Wiring Printout
- [8] Flow Diagram
- [9] Field Wiring Diagram
- [10 & above] Any Special Drawings

All drawings may be prepared on multiple sheets.

When contacting Nol-Tec for assistance, having the complete drawing number to be discussed at hand will speed our efforts to assist you.

The drawings you must have in your possession before the start of installation, their title and intended use, are as follows:

### General Arrangement [1]

This drawing shows the general location of equipment and how it will be installed in your facility. It is only used to receive approval from the customer regarding scope of supply, location, and interface of the components supplied by Nol-Tec Systems. It is not to be used for equipment installation.

### Installation Detail [2]

A mechanical drawing showing the details required for installing the components that come in contact with and convey the material. These components range from inlet valves, transporters, convey line air assist assemblies, switches and couplings to silos, bins, chutes, feeders, etc. These drawings contain dimensions, field erection notes and details relative to the mechanical portion of the system.

### Piping Diagram [3]

This drawing shows control air piping required to the various components of the system. It is very important to note this drawing is not to scale. Actual system layout is shown on the Installation Detail. This drawing is to be utilized by the mechanical and contractors, and should be followed exactly.

### Electric Control Assembly [4]

An electrical drawing which shows the layout of control enclosure internal components, as well as pushbuttons, selector switches, and pilot lights of the control enclosure.

### Equipment List [5]

This is a computer printout of all items that are provided to you by Nol-Tec. The item numbers on this printout relate to balloon numbers that appear on the Installation Detail [2], Piping Diagram [3], and the Wiring Diagram [9]. Only those items shown on this printout will be provided by Nol-Tec Systems. All other items required for the installation of the equipment must be provided by the installation contractor or customer. A typical equipment list heading follows:

## Typical Equipment List:

### SINGLE LEVEL BILL

CATALOGUE NO. : 12345  
ABC COMPANY  
PROJECT DESCRIPTION

ITEM	SUBPART	QTY	UOM	PSM*	DWG	SIZE	RL	DESCRIPTION
A001	13946	1		M				TRANSPORTER, 10 CU.FT., MS,ASEM 3'-0" DIA NOL-TEC 1334F-11
A002	10208	1	EA	S				COUPLING, STYLE 99, 10" VICTAULIC 99-10-E

\*P = PURCHASED PART      S = STOCKED PART      M = MANUFACTURE - NOL-TEC ASSEMBLED

#### Electric Schematic [6]

This drawing is an electrical ladder-type drawing showing the working schematic of the entire system (including the internal wiring of the main control enclosure). This drawing will also show interlocks with other related equipment and takes precedence over the Field Wiring Diagram [9].

#### I/O Wiring Printout [7]

This drawing is an electrical ladder-type printout showing connections between input/output modules and field equipment, when a programmable controller is used. This drawing takes precedence over the Field Wiring Diagram [9].

#### Flow Diagram [8]

This drawing, when utilized, is a concept drawing depicting the entire system. This drawing also indicates all major pieces of equipment and shows system flow.

#### Field Wiring Diagram [9]

This drawing shows the wire connections required to the various components of the system. It is very important to note this drawing is not to scale. Actual system layout is shown on the Installation Detail. This drawing is to be utilized by the electrical contractor.

## CODES AND STANDARDS

All equipment should be installed according to accepted industry standards for the appropriate trades used. Only qualified craftsmen should be used to insure safe and proper installation. In all cases, local and national building codes must be followed for installation.

Qualified Nol-Tec field installation supervision is available. Consult Nol-Tec Service Department for details.

## INSTALLATION PROCEDURE

Before installation begins, a thorough review should be made of all drawings to determine if any discrepancies between drawings and site exist. This will eliminate any delays during construction.

Access to construction areas should be provided to prevent work stoppages and the various crafts should be coordinated for maximum efficiency.

For best results, installation should begin at either end of the conveying line, using working points and dimensions provided on Installation Detail drawing(s). DO NOT start installation in the middle and work toward the end.

The following is a sequence of installation for a typical Nol-Tec system:

- 1) Install silo, hopper or other equipment feeding transporter, if applicable.
- 2) Set transporter in position and level, aligning inlet flange so it is centered with the mating feed equipment. (Refer to COMPONENT INSTALLATION, Transporter for details.)
- 3) Install inlet and vent valves using flanged adapters, only if all welding is complete on the inside of hopper above. (Refer to COMPONENT INSTALLATION, Butterfly Valves for details.) Bolt quantities and sizes are on fastener schedule. Consult Butterfly Valve Installation Manual for proper torque on bolts.
- 4) Determine exact location of working point for conveying pipe riser or first elbow in system.
- 5) Fabricate rigid pipe supports to prevent pipe movement, and tie into available or added structural steel to anchor conveying pipe and bends. Use prefabricated U-bolts or other commercially manufactured strapping devices for pipe. Threaded rod is not adequate and will lead to pipe movement and premature wear. Keep in mind, pneumatic conveying systems and the material traveling through the pipe will generate dynamic forces due to material movement in the conveying line.

NOTE: All conveying pipe longer than 4'0" should be rigidly supported in two places. The couplings provided do not align the pipe. Therefore, accuracy and craftsmanship must be exercised to insure a high quality, maintenance-free system. Tubing and bend support locations are shown on the Installation Detail drawing(s).

- 6) Lay out conveyor pipe between transporter and first working point and install transporter outlet. (Refer to COMPONENT INSTALLATION, Transporter Outlet for details.)
- 7) Install conveyor pipe. (Refer to COMPONENT INSTALLATION, Pipe, Conveyor for details.)
- 8) Tighten conveyor pipe couplings to proper bolt torque as shown in specific coupling installation manual.
- 9) Install pipe bend or elbow at working point. (Refer to COMPONENT INSTALLATION, Pipe Bends for details.)
- 10) Determine next working point shown on Installation Detail drawing(s), and lay out conveyor pipe between it and the portion just previously completed.
- 11) Continue with system installation following above procedures. Remember, work in one direction only. DO NOT start at both ends and work toward the middle.
- 12) Locate air assist assemblies as shown on Installation Detail drawing(s). (Refer to COMPONENT INSTALLATION, Air Assist Unit for details.)
- 13) Switches and diverters should be installed as shown on the Installation Detail drawing(s). (Refer to COMPONENT INSTALLATION, Switches for details.)
- 14) Receivers should be installed only after all pipe, bends and supports have been installed. (Refer to COMPONENT INSTALLATION, Receivers for details.)
- 15) Dust collectors must be installed dust-tight on frames specified on Installation Detail drawing(s). (Refer to COMPONENT INSTALLATION, Dust Collectors for details.)

## AIR PIPING

The air piping for the Nol-Tec system must be installed with care and accuracy to insure the proper quantity and quality of air is delivered to the appropriate use points shown on the Piping Diagram. (Refer to COMPONENT INSTALLATION, Air Controls and System Pressure Controller for details.)

There are two air supply systems required on each Nol-Tec system.

High pressure plant air required for operation of air cylinders and supply to the air assist units.

Pilot control air for air assist assemblies that regulate air supply pressure for material conveying.

Although these two air piping systems perform entirely different functions, the methods and procedures for installing them should be identical.

High quality 150# black iron pipe and fittings should be used and installed using acceptable industry standards and procedures.

The Piping Diagram for the system you are installing should be followed in every detail to insure proper system performance. If any questions should arise, contact the Nol-Tec Engineering Department for details.

The following is a checklist of procedures to follow and consider when installing both air piping systems:

- ☐ All pipe deburred with machine chips removed.
- ☐ Unions should be installed using good piping practice.
- ☐ All pipe runs should be direct with a minimum number of fittings.
- ☐ Shut-off valves should be provided for all high pressure devices.
- ☐ Valves, regulators and filters should be accessibly located.
- ☐ System pressure control assemblies must be located within 20 lineal feet (of piping) of transporter and within 5 lineal feet of a blender/transporter vessel.
- ☐ Safety relief valve and emergency transporter bleed valve outlet should be piped to prevent personal injury.
- ☐ All procedures shown on the Control Piping Diagram general notes must be followed.
- ☐ All air lines must be purged of foreign material before being connected to components (regulators, solenoids, etc.)

## INSPECTION AND START-UP

After all equipment has been installed, a thorough check must be made of all components to assure that the system is installed exactly as shown on the drawings provided. This inspection is very critical to assure a correct functioning system that will provide maximum trouble-free service.

A general purpose checklist of items that should be inspected prior to having qualified Nol-Tec personnel start-up your system follows. By reviewing each item thoroughly, you will insure a smoother, trouble-free start-up with maximum safety.

Do not attempt start-up of any equipment without having qualified Nol-Tec personnel present to review the checklist provided and to make other adjustments necessary for proper operation.

For any items not included on the general purpose checklist, consult the Nol-Tec Service Department for details related to start-up.



## START-UP CHECKLIST

Be sure that the material being handled is the same as specified in our proposal and stated on Installation Detail drawing(s). Any deviation could affect system performance. The following is a checklist to be reviewed prior to start-up:

### Electrical Components

- ☐ Proper power supply connected to electrical control panel.
- ☐ Terminations correctly made to electrical control panel.
- ☐ Electrical control panel and field terminations have wire numbers installed.
- ☐ Limit switches wired and set correctly.
- ☐ Level controls wired and calibrated correctly.
- ☐ Conveying line switches and diverters wired correctly.
- ☐ System pressure control assembly wired correctly.
- ☐ Butterfly valve assemblies wired and set correctly.

### Compressed Air Supply

- ☐ Required volume of air available.
- ☐ Required pressure of air available (80-125 PSIG).
- ☐ Required dryness of air available.
- ☐ Compressor piped properly.
- ☐ Dryer located before air receiver tank.
- ☐ Air receiver tank sized correctly.
- ☐ Control air clean and dry.
- ☐ Air filter installed, if required.

### Pneumatic Piping

- ☐ No air leaks.
- ☐ All air cylinder ports piped correctly.
- ☐ Air piping per Nol-Tec prints.
- ☐ Check valves installed properly per flow arrows.
- ☐ Solenoid valves piped correctly including those on dust collectors.
- ☐ Hoses installed correctly, no kinks or restriction.
- ☐ System pressure control panels located per print and operate correctly.
- ☐ Regulators, oilers and filters installed in proper sequence and operational.

### Mechanical Components

- ☐ Transporters located correctly.
- ☐ Transporters set correctly - straight, level and lagged to the floor.
- ☐ Transporters cleaned of installation debris.
- ☐ Butterfly valves aligned and manually operated - no flange gaskets used - flat and lock washers used.
- ☐ Conveyor line located per drawing(s).
- ☐ All pipes aligned.
- ☐ All supports adequate.
- ☐ Couplings installed to specifications.
- ☐ Air assist assemblies correctly installed (air inlets at top, flow direction correct).
- ☐ Conveying line switches installed correctly.
- ☐ Switches aligned correctly.
- ☐ Receivers installed correctly.
- ☐ Dust collectors installed correctly.
- ☐ Bins or hoppers installed correctly.
- ☐ Silos installed correctly.
- ☐ Level controls installed in the correct position for the application.
- ☐ Level controls calibrated.

### Weigh System

- ☐ Load cells installed correctly.
- ☐ Load cell cables of the proper type utilized and installed in separate conduits.
- ☐ Load cell junction boxes installed as required.
- ☐ All load cell cable terminations complete.
- ☐ Scales calibrated.

## FIELD MODIFICATIONS

All field modifications approved by **Nol-Tec** and implemented should be noted on **Nol-Tec** drawings and returned so existing records can be revised and kept up-to-date for future reference.



## COMPONENT INSTALLATION

Air Assist Units .....	11
Air Controls and System Pressure Controller.....	11
Air Activated Gravity Conveyors .....	11
Blending Cone .....	12
Butterfly Valves .....	13
Couplings, Plain End Pipe Grip .....	13
Couplings, Grooved - End .....	13
Couplings, Compression.....	14
Dust Collectors.....	14
Electrical Control Assembly.....	16
Fasteners .....	16
Knife Gates .....	16
Level Controls .....	16
Pipe, Conveyor .....	17
Pipe Bends.....	17
Receivers .....	17
Slide Gates .....	17
Switches, Automatic Two-Way.....	18
Switches, Manual Hose .....	18
Transporter .....	19
Transporter Outlet .....	19

## AIR ASSIST UNITS

- 1) Install air assist units exactly as shown on Installation Detail drawing(s), as follows:
- 2) Locate air assist unit placement and drill 3/4" diameter hole on top centerline of conveying tubing. Never install on sides or bottom of bottom of tubing. 45 degree maximum either side of top of tubing is permissible for 3/4" diameter hole.
- 3) Position 3/4" coupling or weld-o-let on pipe, and weld into position. Clean hole and remove all internal shavings, weld slag and splatter.
- 4) Install air assist unit controls as shown on Control Wiring and Piping drawing(s).
- 5) The pilot regulator must be installed in the horizontal position.
- 6) The pilot regulator must be at a higher elevation than the connection to the convey line.

## AIR CONTROLS AND SYSTEM PRESSURE CONTROLLER

- 1) Air piping drawing(s) have been provided for ease of maintenance and should be followed exactly.
- 2) Be sure that all pipe ends have been deburred and cleaned internally of shavings before piping to minimize damage to solenoid valves, air cylinders, etc.
- 3) Locate the main system pressure controller above ground, if possible, within 20 feet of the transporter so that regular preventive maintenance can be performed. Do not locate system pressure control in an inaccessible location.
- 4) All pipe sizes shown on the air piping drawing(s) should be followed exactly.
- 5) Check to be sure that filters, regulators, solenoid valves and check valves are not installed backward.
- 6) Air supply to the system pressure controller should be 80-100 PSIG (unless specified otherwise) and sized for air consumption as indicated on drawing(s).
- 7) Pressure switch air line should be piped with a minimum of 12" of vertical 1-1/2" pipe. The remainder must be piped with 1/4".

## AIR ACTIVATED GRAVITY CONVEYORS

- 1) Air activated gravity conveyors (AAGC's) must be installed starting from the fixed outlet and work toward the adjustable inlet.
- 2) All AAGC's are shipped in maximum 20 foot lengths to eliminate field work. Care should be taken when installing, that the drawings are followed exactly to insure the correct sections are installed in their appropriate position.
- 3) The outlet of the AAGC should be aligned with the inlet of the receiving hopper on bin, and supported.
- 4) The next adjacent section should then be installed, working toward the inlet section, which has an adjustable inlet collar, to compensate for any length variations.
- 5) The degree of slope must be maintained per the Installation Detail drawing(s) for proper fit up.
- 6) The adjustable inlet should be positioned and aligned with the discharge feeding hopper or bin and continuously welded in place air tight. There is a protective sheet metal covering which must be removed from the interior of the AAGC after this welding is completed to allow for material flow. This part may be removed by taking the back cover of the AAGC off and sliding it out.
- 7) Support should be adjusted and securely fastened and inlet and outlet connections secured.
- 8) AAGC air supply must be piped exactly as shown on the assembly drawing or system Piping Diagram.

## BLENDING CONE

Before installation of the blending cone, a thorough review of the blending cone installation drawing, D-244-801, and the assembly drawing, D-244-800, is recommended.

### Blending Cone to Blending Vessel

An 18" grooved-end pipe coupling is used to attach the blending cone to the blending vessel. For assembly, proceed as follows:

- 1) Check coupling gasket supplied to be certain it is not damaged.
- 2) Lubricate gasket by applying a thin, uniform coat of silicone lubricant using either one of the following methods:  
  
Method 1: Brush lubricant on pipe ends around entire pipe circumference and inside coupling housing.  
  
Method 2: Brush lubricant on rubber gasket lips (I.D.) and outside of gasket.
- 3) Slide coupling gasket onto blender vessel flange.
- 4) Raise blending cone until flange on blender and flange on bottom of blending vessel mate. The two flanges must be concentrically aligned.
- 5) The 18" grooved-end coupling has a four-part housing. Assemble two quarters and torque bolts making coupling into two parts.
- 6) Center the coupling gasket over the joint between the two mating flanges.
- 7) Affix two flanges together with halves of 18" coupling.

CAUTION: Extreme care must be taken to assure coupling has full contact with flange edges. Failure to do this may cause harm to personnel or equipment.

- 8) Tighten nuts uniformly, alternating sides, until bolt pads are firmly together (metal to metal contact).

### Butterfly Valve to Blending Cone

To attach the butterfly valve to the discharge of the blending cone, proceed as follows:

- 1) The butterfly valve should be oriented per the installation drawing and lifted up into position.
- 2) The blender outlet must be oriented per the system installation drawing, lifted into position, and used to secure the butterfly valve to the blending cone. Bolts with lockwashers as

specified on the installation drawing are to be used to fasten it into position.

- 3) The butterfly valve must be installed in the open position and bolts tightened evenly.

**Do not use flange gaskets. Lockwashers must be used.**

CAUTION: Care must be taken to insure the proper positioning of the discharge butterfly valve between the mounting flanges. The valve must be perfectly centered between both top and bottom flanges. If it is not, the butterfly valve seat could be pinched between the valve disk and the sharp edge of the mounting flange damaging the seat and causing leakage and blow-by.

- 4) Once the butterfly valve has been properly installed, apply air to the actuator and cycle the valve to insure valve operates smoothly. Close valve and check butterfly disk to insure it is centered and fully seated.

### Blending Cone Manifold to Blending Cone

To connect the blending cone manifold to the blending cone, proceed as follows:

- 1) Connect filtered and regulated blending air to the 2" diameter blending cone manifold supply port. (See Piping Diagram for system if applicable.)
- 2) Connect blending cone manifold to each of the six (6) individual piston manifolds using 1" hose assemblies.

### Air Supply, Control

- 1) Air control supply piping should be at least 1/2" NPT. Insure air piping is kept free of all chips and debris during installation.
- 2) Filtered, non-lubricated air at 80 PSIG minimum is required, unless specified otherwise.
- 3) Connection required to port "P" on piston air cylinder and discharge butterfly valve solenoids.

### Electrical

Make electrical connections in accordance with applicable electrical codes and Field Wiring Diagram when applicable.

### General

Verify that all fasteners are tight and air connections do not leak.

## BUTTERFLY VALVES

- 1) The butterfly valves should be installed in the open position, and bolts tightened evenly.

**Do not use flange gaskets. Flat and lock washers must also be used.**

CAUTION: Care must be used in properly aligning the butterfly valve body between the mounting flanges. Valve must be perfectly centered between both top and bottom flanges. This must be done with the valve in the open position. If the valve is not, the butterfly valve seat could be pinched between the valve disk and the sharp edge of the mounting flange, damaging the seat and causing leakage and blow-by.

- 2) Once the butterfly valve has been properly installed, apply air to the actuator and cycle the valve to insure valve operates smoothly. Close valve and check butterfly disk to insure it is centered and fully seated.

## COUPLINGS, PLAIN END PIPE GRIP

After pipe and components, such as switches and receivers, have been properly aligned and rigidly secured, the couplings may be installed.

NOTE: The coupling will not align the conveyor tubing.

Install as follows:

- 1) Mark pipe 15/16" from end.
- 2) Check coupling gasket supplied to be certain it is not damaged.
- 3) Place gasket on one pipe end, butt pipes and center the gasket between the marks made in Step 1.
- 4) Install housings over gasket. Insert bolts and start nuts. (All sizes of plain end, pipe grip couplings, except 1-1/2", have a tongue and recess design and must be properly mated.)
- 5) Tighten nuts uniformly to torque specification for coupling size.

## COUPLINGS, GROOVED-END

After pipe and components, such as switches and receivers, have been properly aligned and rigidly secured, the couplings may be installed.

NOTE: The coupling will not align the conveyor tubing.

Install as follows:

- 1) Check coupling gasket supplied to be certain it is not damaged.
- 2) Lubricate gasket by applying a thin, uniform coat of silicone lubricant using either one of the following methods:

Method 1: Brush lubricant on pipe ends around entire pipe circumference and inside coupling housing.

Method 2: Brush lubricant on rubber gasket lips (I.D.) and outside of gasket.

- 3) Place gasket on one pipe end, butt pipes, and center the gasket over the joint between the pipe ends.
- 4) Install housings over gasket. Insert bolts and start nuts.
- 5) Tighten nuts uniformly to torque specification for coupling size.

## COUPLINGS, COMPRESSION

After pipe and components, such as switches and receivers, have been properly aligned and rigidly secured, the couplings may be installed.

NOTE: The couplings will not align the conveyor tubing.

Install as follows:

- 1) Be sure outside surface of pipe is dry and free of dirt, grease, or external burrs. (Burr and jagged pipe ends can cut gasket; dirt and grease can cause coupling slippage.)
- 2) Grasp coupling to keep gasket, sleeve, and gasket protector in separate quadrants. Be sure gasket teeth mesh and do not overlap.
- 3) Slide coupling over one pipe, past end, then butt pipe ends. Slide coupling back until coupling and gasket protector is centered over joint. Use care when slicing coupling into place. Avoid wrinkling or overlapping gasket or gasket protector.
- 4) When static electricity bleed path is required, a grounding strip should be used.
- 5) Partially tighten bolts uniformly to insure proper seating of inner sleeve and gasket.
- 6) Tighten bolts evenly, as follows:

5/16 bolt size	12 ft. lbs. torque
1/2 bolt size	43 ft. lbs. torque
5/8 bolt size	65 ft. lbs. torque
3/4 bolt size	95 ft. lbs. torque

Where SAE Grade 5, 5/8 bolts are specified, tighten to 95 ft. lbs. For couplings with aluminum shell and inner sleeve do not exceed 40 ft. lbs.

- 7) When properly and evenly tightened to the recommended torque, the coupling installation is complete. The top edges of the flanges will touch and flanges appear as a "V" when viewed from the end.
- 8) Do not attempt tightening bolts to flatten flange faces together, as this exceeds recommended limits.

## DUST COLLECTORS

Install dust collector(s) on mounting flange exactly as shown on Installation Detail drawing(s). A high grade silicone-type caulking is recommended. Place caulking on mounting flange in an adequate quantity to ensure a dust-tight seal. Fasten to mounting flange using 3/8" UNC bolts, nuts and lock washers as indicated on fastener schedule.

### Bag and Cage Installation

- 1) Slip the Bag over the Bag Cage. Bag seam to be opposite side of gap in cage.
- 2) Fold the top two (2)" of the Bag over the seal ring at the top of the Cage, smoothing out all of the folds on the interior. The Bag material must not overlap the Annular Ring.
- 3) Slide the Bag and Bag Cage onto the Bag Cup until the Annular Ring on the Cage snaps into the corresponding groove on the Bag Cup.
- 4) Place a clamp around the Bag 1 – 1 ½" below the tube sheet and feed the slotted end of the clamp under the worm screw. Locate worm screw between bag seam and gap in cage. The Bag Clamp must be in the correct position or a poor dust seal may result.
- 5) Tighten the clamp until the Bag cannot be rotated about the Bag Cup by hand.

NOTE: Improper cage and bag installation will cause dust to leak to atmosphere. Special care in installation will prevent this.

### Manifold Installation (Installed at factory)

- 1) Insert short end of angle valve onto manifold pipe stubs.
- 2) Hand-tighten fittings.
- 3) Insert long ends of valves onto pipe stubs on housing and slide assembly into position.
- 4) Bolt manifold into place.
- 5) Tighten fittings on angle valves using pipe wrench. DO NOT over-tighten.

### **Control Assembly Installation**

- 1) Remove loose fittings and hose from interior of control enclosure shipping carton.
- 2) Remove 3/8" bolts, nuts, and lock washers from front of manifold and use to bolt control enclosure to tabs provided on manifold.
- 3) Cut polytubing to appropriate lengths and push into fittings to complete connection between valve on enclosure and angle valve on dust collector. If polytubing is not inserted properly in fittings, the angle valve will continuously pass air.

### **Weatherhood and Birdscreen Installation**

- 1) Slip hood over stub located near top of collector and fasten with sheet metal screws.

### **Air Connection**

- 1) Connect clean dry air to the manifold of the dust collector as shown on Control Wiring and Piping drawing(s). A service valve and air pressure gauge is recommended.

### **Magnehelic Gauge Assembly**

- 1) Install the two 1/8" pipe plugs supplied with the magnehelic gauge, into the high and low pressure side ports of the magnehelic gauge.
- 2) Install the 1/4" by 2" long pipe nipple in the high pressure (dirty air plenum) port in the dust filter housing.
- 3) Install the 1/4" tee onto the pipe nipple from the filter housing.
- 4) Install the second 1/4" by 2" long pipe nipple in the 1/4" tee.
- 5) Screw the needle valve into the second 1/4" by 2" pipe nipple, with the flow direction (arrow) towards the dust filter housing.
- 6) Install two 1/4" by 1/8" reducing bushings, one in the 1/4" port in the low pressure (clean air plenum) port and the other in the purge line tee.
- 7) Install the two hose fittings - one in the low pressure (clean air plenum) port in the dust filter housing, and one in the purge line tee.

- 8) Attach the 3/16" O.D. tube from the low pressure side (clean air plenum) of the dust filter to the low pressure port of the gauge, and from the purge line tee to the high pressure port of the gauge.
- 9) Open purge line needle valve 1/4 to 1/2 turn from the closed position. The small amount of air flow of the purge needle valve should not affect the position of the gauge, but will keep contaminants from the dust filter from backing up into the Magnehelic gauge.

### **Photohelic Gauge Assembly**

- 1) Install the piping the same as described in the Magnehelic Gauge Assembly section.
- 2) Remove three (3) screws on the back cover of the gauge. This will remove the back cover of the gauge for wiring and conduit connection.
- 3) Install 1/2" flexible conduit between Photohelic gauge cover and Timer board enclosure. Support this conduit to prevent undue strain on the instrument.
- 4) Terminate Photohelic Gauge to Dust Filter Timer board as described on page 5, and on Dwyer bulletin B-33.
- 5) Set adjustable pointer to 6" on the gauge front scale. This will now signal the bags to clean when the differential pressure reaches this set point. This is only an approximate set point, your situation may call for a different setting.

## ELECTRICAL CONTROL ASSEMBLY

The electrical control cabinet should be installed in an accessible area, safe for operating personnel.

Suggested Location:

- 1) Install **away** from traffic area, where heavy equipment such as fork lifts, are operating.
- 2) Position so cabinet door(s) can fully open. A minimum of three feet clearance in front of doors is suggested.
- 3) Protect from weather, adjacent water lines, drains, etc., which may damage electrical components.
- 4) Do not install near an excessive vibration area.
- 5) Cabinet should be located where visual and audible alarms can be monitored if situation arises - near system pressure controller and transporter if possible.
- 6) Protect cabinet from contacting product being handled. Excessive dust and accumulation on cabinet may create maintenance problems.
- 7) Field wiring shall conform to local and national electrical codes.
- 8) Do not run wire not associated with Nol-Tec equipment through control cabinet, if at all possible. Remote cabinets (when applicable) should be given the same consideration.
- 9) All electrical cabinets should be permanently secured in place.

## FASTENERS

- 1) All fasteners for attaching and connecting equipment during erection are the responsibility of the customer or installation contractor.
- 2) Fasteners used on pressure vessels should be a minimum of SAE Grade 1, or ASTM A307, with coating to prevent rusting. Fasteners used on all other components should be SAE Grade 5, or ASTM A325 with coating to prevent rusting.
- 3) A fastener schedule is provided on the installation detail to inform the supplier of the size, length and quantity that is required. The quantities indicated are exact, leaving the amount of overage on each item to the installer's discretion.

## KNIFE GATES

- 1) Knife gates must be installed exactly as shown on the Installation Detail drawing(s).
- 2) The orientation of the knife gate and adequate clearance for the hand wheel operator or air cylinder must be considered.
- 3) Knife gates must be installed between two 150 pound flanges, with ring or full face gaskets on both sides of valve.
- 4) See fastener schedule for proper bolt diameter and length.

## LEVEL CONTROLS

Nol-Tec Systems utilizes a capacitance-type level control, with either the standard probe or cable extension. The calibration is done via an adjusting screw inside the cover.

- 1) Level controls installed in transporters must be located low enough to allow the inlet valve to close completely before material backs up into the valve, overfills the transporter and prevents valve from closing.
- 2) All level controls used to indicate high level in silos, receiving bins or hoppers, fed by a transport system, should be located low enough so that after it is actuated (covered) there is room for at least one full transport batch of material above the level control.



## PIPE, CONVEYOR

- 1) All straight pipe should be saw cut and the ends dressed square. All nicks, burrs, and rough edges should be removed. Do not attempt to cut the conveyor pipe with a torch.
- 2) Each piece of conveyor pipe, including pipe bends, should be supported independently and rigidly so that it can be removed without disturbing the alignment of an adjacent piece of pipe. Any pipe section in excess of four feet, must have at least two supports.
- 3) Important: All runs must be level, plump, in-line, and straight from end-to-end with no misalignment at pipe joints to cause excessive and/or premature wear.
- 4) Pipe bends and straight pipe may have a tendency to sway or move laterally and must have rigid support.
- 5) Do not weld sway braces, hangers or connect auxiliary equipment to the conveyor pipe.
- 6) U-bolts or strap clamps which contact pipe should be used.
- 7) The conveyor pipe has been designed to butt together. There should be no gaps between pipe joints.
- 8) Please consult the Nol-Tec Mechanical Engineering Department for recommendations.

## PIPE BENDS

CAUTION: Total ceramic pipe bends and wear resistant elbows are very fragile. They must be handled with care to prevent damage.

- 1) Pipe bends must be installed exactly as shown on the Installation Detail drawing(s). Air assist unit placement is selected according to location of these bends. Consequently, any variations may adversely affect the performance of the system. Nol-Tec will assist you if, for any reason, changes must be made.
- 2) Support of the pipe bends is very critical due to the dynamic forces generated by the material in the conveying line. All pipe bends must be rigidly supported with structural steel using holes in end plates on backed pipe bends, or commercially available fasteners as described in conveying line support section of this manual.

## RECEIVERS

- 1) Receivers should be installed only after all tubing, bends, and supports have been installed.
- 2) The receivers should be set in place per the Installation Detail drawing(s), and welded in place with an airtight continuous weld.
- 3) Receivers may be set on top of flanges, or set into receiving tank, depending on design.
- 4) Correct alignment of tubing to inlet stub is important. Misalignment can cause premature wear, particle degradation, or system plugging.

## SLIDE GATES

- 1) Slide gates must be installed exactly as shown on Installation Detail drawing(s).
- 2) The orientation of the slide gate and adequate clearance for the removal and placement of the slide gate must be considered.
- 3) Weld or bolt slide gate in place, dust-tight, after checking alignment.



## SWITCHES, AUTOMATIC TWO-WAY

Switches are shipped in either right or left-hand configurations. Check that the switch is correct for your application. Before installation is started, a thorough review of the Installation Detail drawing(s) is recommended.

### Setting, Securing, and Guarding

- 1) Switch must be installed with independent rigid support, free of, but aligned with, conveyor pipe and bolted in place. **DO NOT weld on switch.**
- 2) A service platform is recommended to provide adequate accessibility for inspection and maintenance.
- 3) Provide service stubs on inlet and outlet pipe sections as shown on Installation Detail drawing(s).
- 4) Install suitable guards, as required, to protect personnel from injury during operation and to protect the switch from external damage.
- 5) For outside applications, switch must be protected from rain, snow and ice. Nol-Tec offers optional weather covers for this purpose if you desire.

### Air Supply

- 1) Air control supply piping should be at least 1/2 " NPT. Insure air supply piping is kept free of all chips and debris during installation.
- 2) Filtered, non-lubricated, air at 80 PSIG minimum is required, unless otherwise specified.

### Electrical

- 1) Electrical connection to be made in accordance with applicable electrical codes and the Field Wiring Diagram.

## SWITCHES, MANUAL HOSE

- 1) Install the center riser (manual hose switch adapter) of a group at height shown on Installation Detail drawing(s).
- 2) Attach manual hose discharge to this riser and establish longest hose length with radius as specified on drawing. Field cut tubing that attaches to inlet of manual switch.
- 3) With inlet attached, establish heights of other manual hose switch adapters, again using a radius as close to nominal dimension shown on drawings.
- 4) Proceed to connect all manual hose switch adapters in the same manner.
- 5) When all connections have been made, firmly support conveying pipe on inlet and outlet of manual hose switch.

## TRANSPORTER

- 1) Locate transporter according to Installation Detail drawing(s).
- 2) Manhole or handhole in transporter should be located for easy access and according to Installation Detail drawing(s).
- 3) Access to at least two sides of the transporter should be furnished.
- 4) Shim or grout the transporter legs so that the transporter is straight and level and that it conforms to the tubing arrangement drawing.
- 5) Permanently bolt the transporter to the floor. Bolt holes in legs are provided.
- 6) Each transporter has:
  - Four (4) 1 1/2" couplings on top head:
    - One (1) to accept safety relief valve and emergency bleed.
    - One (1) to accept level control (if used).
    - One (1) for main air inlet.
    - One (1) as a spare.
  - Two (2) minimum, twelve (12) maximum, conical bottom jet connections.
  - One (1) 360 degree rotating outlet.
- 7) Inspect manhole bolts and tighten as they may loosen during shipment.
- 8) If the transporter is located in a pit, provide a sump pit with a sump pump (if necessary) to keep pit dry.
- 9) Wherever possible, all threaded openings on the top of the transporter should be left in the clear to make room for possible piping and equipment.

## TRANSPORTER OUTLET

- 1) The transporter outlet is attached utilizing a grooved-end pipe coupling.
- 2) Place the flange ends of the transporter and transporter outlet face-to-face and slip the grooved-end pipe coupling gasket around the circumference of the pipes.
- 3) Place the two halves of the couplings around the pipe with the lip of the coupling catching the top and bottom of the respective pipe.
- 4) Install bolts in coupling and torque until vertical surface of couplings bottom out.



# INSTRUCTIONS FOR STORAGE OF NOL-TEC EQUIPMENT



**[www.nol-tec.com](http://www.nol-tec.com)**

425 Apollo Drive • Lino Lakes, MN 55014

Telephone US 651-780-8600

©August 2007

## **STORAGE OF EQUIPMENT**

After receiving, unloading, and inventory of your Nol-Tec supplied equipment, particular consideration must be given to storage. All shipments of Nol-Tec equipment are for immediate installation and start-up. No provisions have been made for extended storage, or storage in an area which is unsuitable for mechanical equipment.

Many pieces of equipment have working surfaces that may corrode if not given special attention. Consequently, warranties and guarantees cannot be honored when it is apparent good storage procedures have not been exercised prior to installation.

After reviewing these instructions, should questions arise regarding storage or extended storage, please contact the Nol-Tec Mechanical Engineering Department.

## **INDOOR STORAGE BUILDING - NOT CONTAINER (Without Climate Control)**

The following types and pieces of equipment must be stored in a dry, temperate atmosphere to prevent damage from corrosion, deterioration, etc. Refer to Page 6 of this manual for Storage Precautions prior to placing any equipment into storage or extended storage.

### **3A DAIRY EQUIPMENT**

### **COMPUTER EQUIPMENT**

### **CONTROL PANELS OR ENCLOSURES**

### **ELECTRIC ACTUATORS**

### **FILTER BAGS**

### **FILTER CARTRIDGES**

### **FLEX WALL FEEDERS**

### **LINEAR TRANSDUCERS & POTENTIOMETERS**

### **PIPE INSULATION**

### **PRINTERS**

### **ROTARY VALVES**

### **SCREENERS**

Equipment not listed, but that should be considered for **Indoor Storage** include items that are not packaged for outdoor storage, and that will be affected by the elements.

## **COVERED STORAGE**

### **Protection From Rain & Snow**

The following types and pieces of equipment must be stored covered from the weather to prevent damage. Refer to Page 6 of this manual for Storage Precautions prior to placing any equipment into storage or extended storage.

**AIR PAD BOTTOMS**

**AIR ACTIVATED GRAVITY CONVEYORS**

**BAG CAGES**

**BAG DUMPS**

**BIN DISCHARGERS**

**BIN FILL VALVES**

**BLEND CONES**

**BLOWER PACKAGE**

**BULK BAG UNLOADERS WITH HOISTS**

**BUTTERFLY VALVES**

**DIVERTERS**

**MAGNETIC GRATES**

**MANUAL HOSE SWITCHES**

**PALLET BOXES**

**PINCH VALVES**

**SCREW CONVEYORS**

**VIBRATORY CONVEYORS**

Equipment not listed, but which should be considered for **Covered Storage** include items that can tolerate wetness, but should not be exposed to long periods of moisture.

## **UNCOVERED OUTDOOR STORAGE**

The following types and pieces of equipment may be stored outdoors. Refer to Page 6 of this manual for Storage Precautions prior to placing any equipment into storage or extended storage.

**BENDS/ELBOWS**

**COUPLINGS**

**CYCLONE**

**DUST COLLECTORS**

**HOPPERS**

**PIPE**

**RECEIVERS**

**SUPPORT STEEL & LADDERS**

**TRANSPORTER**


**VACUUM RECEIVERS**

Equipment not listed, but that should be considered for **Uncovered Outdoor Storage** include items that are supplied or designed for installation and use outdoors.

## STORAGE PRECAUTIONS

1. Check for missing parts prior to storage. Report all missing parts to Nol-Tec Systems. Nol-Tec Systems will not be responsible for parts reported missing after 30 days of shipment.
2. Inspect equipment prior to storage. "Damage in transit" claims need to be filed as soon as possible. Painted equipment should be checked for scratches and gouges, which may occur in shipping and handling. These should be touched-up to prevent rusting.
3. Stored items should have a visual inspection every 3 months.
4. Equipment with motors: Follow manufacture's directions for rotation intervals.
5. Shipping containers holding equipment should be water tight and stored in an area that does not allow the internal temperature to exceed 140° F.
6. Supply pallet boxes with waterproof bases.
7. Add desiccant to pallet boxes & shrink-wrap boxes.
8. Seal all air line openings with plastic plugs or caps.
9. Seal all tank openings with wood covers or duct tape.
10. Do not seal bins or other mechanical equipment with shrink-wrap or other plastic coatings that may promote condensations.
11. Close doors on dust collectors, receiving bins, vacuum receivers, and cyclones to reduce the introduction of moisture.
12. Add desiccant to inside of unpainted bins or containers. Do not contaminate unpainted interior surfaces with oil.
13. Pipe & bends should have plastic end plugs or caps.
14. Mild steel pipe should be coated with lacquer type finish from the mill or finished painted.
15. All electrical junction boxes, control enclosure limit switch boxes, and other electrical enclosures should have desiccant pads and be securely closed.
16. Equipment should be blocked-up off the ground.
17. Thorough inspection of parts is required prior to installation after prolonged storage.
18. Warranty of equipment supplied by other vendors to Nol-Tec Systems will start on the date of receipt of said equipment. Nol-Tec's manufactured equipment warranty will start at the time of commissioning, based on proper storage of said equipment.





# MAINTENANCE SCHEDULE

---



**[www.nol-tec.com](http://www.nol-tec.com)**

425 Apollo Drive • Lino Lakes, MN 55014

Telephone US 651-780-8600

©2004

## ***Important Notice***

Improperly maintained and operated Nol-Tec equipment can result in property damage, and/or serious bodily injury. Failure to properly maintain and/or operate the equipment will void any and all warranties of the manufacturer's workmanship and designs. If you are not qualified, trained and authorized to perform maintenance of the Nol-Tec equipment, report to your supervisor and obtain their direction in these regards.

\*\*\*\*\*

This manual is intended for the User of the equipment manufactured by NOL-TEC SYSTEMS INC., Lino Lakes, MN, USA. It must be read by the operator and the workman installing and maintaining this equipment.

1. This manual describes general use limits and includes technical specifications for installation, maintenance, trouble shooting and parts list. It also includes information on safety devices and instructions about User safety.
2. This manual is an integral part of the equipment and must be kept for reference.
3. The manual should be kept in a safe place.
4. The User can suggest changes to improve this manual to the Manufacturer or his Agent. Suggestions will be appreciated and reviewed to determine merit.
5. The Manufacturer disclaims responsibility in case of:
  - a) Improper use of equipment.
  - b) Use not in compliance with specific laws even if these are subsequent to the sale date of this equipment.
  - c) Incorrect installation.
  - d) Feed damages.
  - e) Serious failure in the expected maintenance.
  - f) Unauthorized modifications to the equipment.
  - g) Removing or deleting the security devices and signals.
  - h) Use of parts manufactured by other than the original manufacturer.
  - i) Total or partial non-observance of the instructions supplied in this manual.
  - j) Exceptional or unpredictable events.
  - k) Improper use of the equipment with materials or in situations not expressly authorized by the Manufacturer.
6. Before moving, installing or using the equipment, carefully read this manual.
7. It is necessary to evaluate carefully the possibility of using this equipment with inflammable, corrosive, explosive materials, or material for which particular precautions are prescribed.

## **TABLE OF CONTENTS**

	Page
<b>AERATION JETS</b> .....	4
<b>AIR ASSISTS</b> .....	4
<b>BUTTERFLY VALVES</b> .....	4
<b>BAG DUMP</b> .....	4
<b>BLENDER</b> – see Blender Manual	
<b>BLOWER PACKAGE</b> .....	4
<b>BROKEN BAG DETECTOR</b> .....	5
<b>CONVEY LINE BENDS &amp; ELBOWS</b> .....	5
<b>COUPLINGS &amp; FLANGE CONNECTIONS</b> .....	5
<b>DUST COLLECTOR / VACUUM FILTER RECEIVER</b> .....	5
<b>DUST COLLECTOR CONTROL ENCLOSURE</b> .....	5
<b>DUST COLLECTOR MAGNEHELIC GAUGE ASSEMBLY</b> .....	5
<b>DUST FILTER – SINGLE CARTRIDGE</b> .....	5
<b>DUST FILTER BAGS</b> .....	5
<b>LEVEL CONTROLS</b> .....	6
<b>LOSS-IN-WEIGHT FEEDERS</b> .....	6
<b>MANUAL HOSE (SWITCH)</b> .....	6
<b>ROTARY AIRLOCK</b> .....	6
<b>SCREW CONVEYOR</b> .....	6
<b>SURGE HOPPER</b> .....	6
<b>SWITCH, TWO-WAY HOSE</b> .....	7
<b>TRANSPORTER ASSEMBLY</b> .....	7
<b>VACUUM FILTER RECEIVER</b> – see Dust Collector Pg. 5 .....	5
<b>WEIGH HOPPER</b> .....	8

## Recommended Equipment Maintenance

### AERATION JETS

**Note:** Follow manufacturer's service recommendations.

#### WEEKLY

- + Visually inspect air fittings, hose, etc. for leaks.
- + During normal operation verify aeration air solenoid valve is cycling and airflow to each jet is achieved.

#### MONTHLY

- + From the maintenance screen of the control system, manually open the aeration air solenoid valve. Then individually check each jet by restricting airflow through the jet hose to audibly detect airflow. If no flow is detected, disassemble to remove any foreign material.

### AIR ASSISTS

**Note** Air assist needle valve settings should be as defined in the "system air control settings" provided in the documentation package.

#### MONTHLY

- + Check hoses. Cracks in the outer cover indicate a leaking hose.
- + Check polytube and fittings for deterioration and air leaks.
- + With convey system at rest, check for audible evidence of airflow through the unit. Airflow indicates dirty or damaged regulator diaphragms.
- + Check each air assist for air flow as follows:
  - Turn transporter selector switch to disable.
  - Manually override the system pilot air solenoid valve to activate all air assists in the convey line.
  - Check each air assist individually by restricting airflow through the air assist hose. An increase of pressure on the air assist gauge indicates airflow through the assembly. If no flow is determined, disassemble and remove any foreign material between conveying line and pilot regulator.

#### ANNUALLY

- + Replace pilot regulator diaphragms.

### BUTTERFLY VALVE

#### WEEKLY

- + Check tubing and fittings for deterioration and leaks.
- + Visually check compressed air filter for water and foreign material in bowl.
- + During normal system operation observe the actuator position indicator for smooth full operation.

#### EVERY 6 MONTHS

- + Check the valve disc and seat for excessive wear. Valves operating with a high-pressure differential should be checked every 3 months.

### BAG DUMP

#### WEEKLY

- + Check polytube and fittings for leaks. If blow-down air is constantly on, the polytube is leaking.
- + Operate the filter cleaning cycle for each of the cartridges to ensure the diaphragm valves are functioning, providing reverse jet cleaning.
- + Visually check exhaust air for dust emission while in operation.

#### MONTHLY

- + Ensure that compressed air supply is 80 PSIG minimum.
- + Verify that pressure regulator is set at 60 PSIG.

### BLENDER

**Note** Refer to Nol-Tec Blender Manual.

### BLOWER PACKAGE

**Note** Follow manufacturer's service recommendations.

#### WEEKLY

- + Check inlet filter for debris and foreign material

#### MONTHLY

- + Check air pump for signs of oil leaks.
- + Check drive belts for excessive wear and proper tension.
- + Verify weighted pressure relief valve is moving freely.

## **BROKEN BAG DETECTOR**

### **EVERY 6 MONTHS**

- + Check wiring in the control head for loose connections.

### **ANNUALLY**

- + Remove probe from the duct and clean off any accumulated dust

## **CONVEY LINE BENDS & ELBOWS**

### **EVERY 3 MONTHS**

- + Visually check exterior of elbow or bend for signs of wearing through.
- + Check inlet and outlet couplings for leakage.
- + Visually check that all bolting hardware is secure.

## **COUPLINGS & FLANGE CONNECTIONS**

### **EVERY 3 MONTHS**

- + Check for leakage.
- + Visually check that bolting hardware is secure.

## **DUST COLLECTOR/ VACUUM FILTER RECEIVER**

### **WEEKLY**

- + Ensure that compressed air supply is 80 PSIG minimum
- + Check polytube fittings for leaks. If blow-down air stays on, the polytube is leaking air.
- + Check filter bags by watching the magnehelic gauge. Bags should be changed when the magnehelic gauge does not go below 6" W.C. after cleaning.
- + Visually check exhaust air for material emission during a convey cycle.

### **MONTHLY**

- + Check door gasket seal. As gasket takes a set it may be necessary to adjust the door hinges. Replace if necessary.

## **DUST COLLECTOR CONTROL ENCLOSURE**

**Note** Repeat cycle timer settings should be per the "system air control settings" provided with your documentation package.

### **WEEKLY**

- + During a normal convey cycle confirm that repeat cycle timer, control solenoid valves and diaphragm valves are functioning to provide the reverse jet bag cleaning.

## **DUST COLLECTOR MAGNEHELIC GAUGE ASSEMBLY**

**Note** Pressure should not exceed 10 inches WC, with the exception of the instantaneous spike at the end of the convey cycle.

### **WEEKLY**

- + Visually check polytubing and fitting for signs of deterioration and leaks.
- + Check that air purge is open.

### **MONTHLY**

- + Verify that the gauge is at zero while system is at rest.
- + During a convey cycle, verify that gauge pressure fluctuates, rising gradually then falling off after each cleaning cycle.

## **DUST FILTER – SINGLE CARTRIDGE**

### **WEEKLY**

- + Visually check exhaust air for dust emissions from filter housing during process.
- + During vessel discharge verify that the cleaning air solenoid valve is cycling and air pulsing is achieved.

## **DUST FILTER – BAGS**

### **WEEKLY**

- + Visually check exhaust air for dust emissions from filter housing during process.
- + During vessel discharge verify that the cleaning air solenoid valve is cycling and air pulsing is achieved.

## **LEVEL CONTROLS**

**Note** To manually check level control, a wooden or metal rod can be used to touch the probe. Be sure that the rod used to touch the probe is without an electrical charge and disconnected from any and all electrical systems.

### **MONTHLY**

- + Remove the cover on the level control unit and check the LED to verify the status. If the probe is not touching material the LED should be on.
- + Low level controls should be checked at the control panel for a positive indicator light. If there is not a high level signal the bin material level should be visually checked. If the probe is completely uncovered it can be manually checked to ensure functionality.

## **LOSS-IN-WEIGHT FEEDERS**

### **WEEKLY**

- + Clean screw and screw tube.
- + Screw: Check for damage - replace if necessary.
- + Sleeves: Check for damage caused by wear, ageing, brittleness or breakage.
- + Sleeves: Check for proper fastening.
- + All Movable Parts: Check to see that no dust or dirt has formed a deposit. Clean all parts as necessary.
- + Check all earth connections.
- + Calibrate load cell on loss-in-weight feeder.
- + Electrical Connections: Check for any mechanical damage.

### **MONTHLY**

- + Shaft Sealing: Check for tightness. In case of a leak, product would fall to the bottom of the housing.
- + Check to ensure all electrical screw connections are well tightened.

## **MANUAL HOSE (SWITCH)**

### **WEEKLY**

- + Check hose for leakage.
- + Check camlock end fitting for secure fit and any signs of leakage.
- + Visually check that bolting hardware is secure.

### **EVERY 3 MONTHS**

- + Visually check inside of hose for excessive wear.

## **ROTARY AIRLOCK**

**Note:** Follow manufacturer's service recommendations. Line plugging after commissioning the system could mean rotor wear.

### **WEEKLY**

- + Inspect for material leakage.

### **MONTHLY**

- + Check gear reducer for signs of oil leaks
- + During operation check for audible detection of a loose chain.

## **SCREW CONVEYOR**

**Note** Follow manufacturer's service recommendations.

### **WEEKLY**

- + Check for material leakage.
- + Check outlet butterfly valve for proper operation. (See butterfly valve checklist.)

### **MONTHLY**

- + Check gear reducer for signs of oil leaks.
- + Check drive belts for excessive wear and proper tension.

## **SURGE HOPPER**

### **WEEKLY**

- + Check all inlet and outlet flexible boot connectors, air and electrical connections to ensure there are no adverse loadings being applied that would affect weighing accuracy.
- + Check hopper top and remove any accumulated materials or foreign objects.
- + Check inside of hopper for any material build-up and remove as necessary.
- + Check discharge butterfly valve for proper operation. (See butterfly valve checklist.)

### **MONTHLY**

- + Check aeration jets (See aeration jet check list.)

## SWITCH, TWO-WAY HOSE

### WEEKLY

- + Check for material leakage.
- + Visually check compressed air filter for water and foreign material in the bowl.
- + Observe the switch operation to ensure the following:
  - Sealing cylinders are retracting to provide adequate clearance of the tube end seal as it swings from position to position.
  - Positioning cylinder is extending and retracting fully. Inspect the backside of the rod stop collar for material buildup that would prevent the cylinder from retracting completely.
  - Position limit switch is being fully actuated by its flag to give a "Position Made" signal.
  - Unseal switch is being fully actuated by its stud bolt to give an "Unseal" signal.
  - Off-leg seal assemblies are making adequate contact to provide for sealing the off-leg convey line of the switch.
- + Check tubing and fittings for deterioration and leaks.
- + Visually check exterior of switch tube for signs of wearing through.
- + Visually check assembly that bolting hardware and all components are secure.

### EVERY 6 MONTHS

- + Visually check inside of switch tube for excessive wear.

## TRANSPORTER ASSEMBLY

**Note** Pilot air pressure and valve settings are to be as defined in the "system air control settings" provided in the documentation package.

### WEEKLY

- + Confirm 80 PSIG minimum air supply to system.
- + Check material inlet connection for leakage
- + Check air operated inlet and vent butterfly valves. (See butterfly valve check sheet.)
- + Check polytube and fittings for deterioration and leaks.

- + Visually check compressed air filter and filter/regulator for water and foreign material in the bowl.
- + With the system at rest check for audible evidence of conveying air flowing. This would indicate that the system pressure control solenoid valve may be stuck or that one or more of the pilot regulators is dirty and stuck in the open position.
- + During a normal transport cycle observe the following basic operations:
  - Vent valve and inlet valve operate simultaneously, closing when the transporter high level control is made.
  - System pressure controller solenoid valve is to open providing pilot air to the system starting the conveying process.
  - The pressure gauge directly downstream from the pressure controller solenoid valve should correspond to the pressure setting of the system pressure regulator. All other pilot line pressure gauges will read something less than that but there will be a reading and this will indicate that there is airflow to each device.
  - When the back pressure in the transporter falls below the high setting of the pressure switch the system pressure controller solenoid valve will close shutting down the system.
  - If batch requirements call for it, there may be a convey line purge at the end of a convey cycle. This would open the purge solenoid valve of the system air controls momentarily.
- + Verify airflow through each of the aeration jet. Procedure as follows:
  - Set transporter selector switch to disable.
  - Manually override the system pilot air solenoid valve to activate airflow through the jets.
  - Individually check each jet by restricting airflow through the jet hose to audibly detect airflow. If no flow is detected, disassemble to remove any foreign material.
  - Recheck to confirm problem was corrected.
  - Return selector switch to enable when procedure is complete.

**VACUUM FILTER RECEIVER SEE DUST  
COLLECTOR/VACUUM FILTER RECEIVER**

**WEIGH HOPPER**

**WEEKLY**

- + Check all inlet and outlet flexible boot connectors, air and electrical connections to ensure there are no adverse loadings being applied that would affect weighing accuracy.
- + Check hopper top and remove any accumulated materials or foreign objects that would put a false load on the scale
- + Check inside of hopper for any material build-up and remove as necessary.
- + Check discharge butterfly valve for proper operation. (See butterfly valve checklist.)

**MONTHLY**

- + Check aeration jets (See aeration jet check list.)



***NOL-TEC SYSTEMS<sup>®</sup>, INC.***

**PNEUMATIC CONVEYING SYSTEM  
OPERATING & TROUBLE SHOOTING  
MANUAL**

**TABLE OF CONTENTS**

	PAGE
INTRODUCTION.....	1
BASIC SEQUENCE OF OPERATIONS .....	1
SAFETY .....	4
MATERIAL BEING HANDLED .....	5
CONVEYING LINE PLUG.....	5
SYSTEM DEPRESSURIZATION PROCEDURE .....	7
TROUBLE SHOOTING GUIDE .....	8
PRESSURE SWITCH SETTING PROCEDURE .....	12
TYPICAL TRANSPORT SYSTEM DIAGRAM .....	14

## INTRODUCTION

This manual is intended to give you a basic understanding of a **Nol-Tec** Pneumatic Conveying System. The information is general in nature and meant to be used along with the prints and manuals supplied by **Nol-Tec Systems** for your specific system. Due to the inter-relationship between the electrical and mechanical functions of equipment, a thorough evaluation of a problem should be made prior to using any of the recommendations.

A typical transport system diagram is shown on Page 14 to help you to understand the system function and to identify specific components referred to in this manual.

## BASIC SEQUENCE OF OPERATIONS

1. Check that the plant air supply to system is turned on.
2. Turn electrical system power on.

### Automatic Mode

3. Start "Automatic" Mode via keyboard or push-button.
  - a. System indicates "Automatic" mode on.
  - b. Transporter inlet and vent valve open and material flows into transporter.
  - c. System indicates transporter "Loading."
4. Material level in transporter reaches its level control.
  - a. System indicates transporter "Full."
  - b. Transporter inlet and vent valves close.

**Note:** To fill transporter, if system is not in automatic, utilize "Man Load" function via keyboard or push-button.

5. Inlet valve closed limit switch is actuated, starting inlet valve closed timer.

**Note:** Inlet valve closed timer is used to insure inlet valve is fully seated before allowing transporter to be pressurized.

6. Inlet closed timer times out - approximately 3 seconds.
  - a. System indicates "Transporting."

- b. Pilot air solenoid valve (7) is turned on, supplying regulated air to system pilot regulators.
- c. The system pilot regulators supply regulated transport air to the transporter and conveying line.
- d. Transport cycle started timer starts timing.

**Note:** Transport cycle started timer is used to hold transport air on until normal transporting pressure is reached in transporter - approximately 15 seconds.

- 7. As pressure in the transporter increases above 2 PSI, transporter pressure switch (3) PS-1 (low) is actuated (opened) inhibiting load cycle.
- 8. As pressure continues to increase to approximately 15 PSI, transporter pressure switch (3) PS-2 (high) is actuated (closed).
- 9. Transport cycle started timer times out. Transport cycle is now held on as long as transporter pressure switch (3) PS-2 is actuated.

**Note:** With the increase of pressure in the system, material is conveyed down conveying line to receiving bin.

- 10. When material level in transporter drops below transporter high level control, transporter "Full" indication is turned off.
- 11. When transporter empties and conveying line clears, pressure in the transporter decreases. When pressure drops below setting on transporter pressure switch (3) PS-2, it is de-actuated (opened).
  - a. "Transporting" indication is turned off.
  - b. Pilot air solenoid valve (7) is turned off, exhausting system pilot air.
  - c. Transport air, to the transporter and conveying line, is turned off.
- 12. As pressure continues to drop, transporter pressure switch (3) PS-1 is de-actuated (closed). Pressure low timer starts timing.

**Note:** Pressure low timer is used to insure pressure in transporter is zero before inlet and vent open.

13. Pressure low timer times out - approximately 3 seconds.

**Note:** If system was not in automatic, a transport cycle can be initiated utilizing the "Man. Transport" function via keyboard or push-button. If transporter inlet is closed, inlet closed timer is timed out and receiving bin level is not high, transport cycle starts. Steps 6a through 13 take place as in automatic.

**Note:** System will continue to repeat steps 3b through 13 until one of the following steps take place:

14.1 Operator stops "Automatic" via keyboard or push-button.

- a. "Automatic" indication is turned off.
- b. If system was in a loading cycle it would stop loading and come to rest.
- c. If system was in a transporting cycle, it would complete transporting cycle and come to rest.

14.2 Receiving bin high level control becomes covered and system will finish transporting cycle and come to rest.

**Note:** The above sequence is for a dual pressure switch system. If system has only one pressure switch, its setting would be approximately 4 PSI. When switch is deactuated, it functions as PS-1, and when actuated it functions as PS-2.

## **SAFETY**

**CAUTION:** *The most important fact to remember during trouble shooting is that the potential for the instantaneous release of high pressure gases mixed with the material being conveyed is a very real danger. Every precaution must be taken to eliminate the risk of property damage or personal injury due to carelessness or improper procedures.*

*The component manuals outline the correct safety measures to follow for each specific piece of equipment. The system as a whole should always be looked upon as being under high pressure, until the person performing maintenance has personally verified otherwise.*

*This hazard exists especially if the system becomes plugged. There are special instructions in this manual for the proper depressurization procedures. Do not attempt to take short cuts. Familiarizing yourself with the manual as a whole is strongly advised.*

*There is also an element of danger electrically. Be sure that anyone working on the system is fully qualified to work with circuitry and voltages provided. Typically, industrial maintenance people are better informed and more aware of electrical hazards than they are with those associated with compressed air hazards. Therefore, the emphasis on the pneumatic hazards.*

**Note:** **Nol-Tec Systems** expressly disclaims responsibility or liability for any injury or damage caused by failure to observe these specified precautions or by failure to exercise that ordinary caution and due care required in operating or trouble shooting the system, even though not expressly specified above.

## MATERIAL BEING HANDLED

Material uniformity and consistency is a very important part of a systems function and performance. **Nol-Tec's** system design is based on the material(s) which will be handled. Deviation from original material specifications could create excessive wear problems, erratic system function and down time. Once system settings and rates have been established for the given material(s), introduction of material which is not to specification may cause unsatisfactory results.

Whenever a significant material change is made due to supply or process change, **Nol-Tec** should be advised. Re-tuning of system or recommended design changes to handle material may be required. Material being delivered to plant process for the most part, will only be as good as the material introduced into system. Educating plant personnel to this fact, will avert unnecessary down time and maintenance.

## CONVEYING LINE PLUG

If a plug should occur, locating the area of the plug is advised. Finding the plug location may aid in determining the cause of the plug such as a worn tubing bend, conveying line switch/diverter malfunction, overfilling receiving station, misalignment of convey tubing, or leaks, in air supply or conveying line. Once system configuration has been established, a plug will only occur when an abnormal function or property has been introduced. Due to the different design applications based on a customer's specific needs, comprehending the following steps for unplugging a system is essential.

1. The first indication of a plugged conveying line is the transport cycle staying on too long. The transporter pressure gauge (2) will read at or near the pilot air pressure gauge (6), in a plugged condition. Gauge (2) should read zero in a non-plug non-convey state. The air control assembly shown is a basic layout. Fully acquaint yourself with your particular system configuration.
2. Locating the plug area can be achieved by monitoring gauges on air assist assemblies. Take special care that all gauges are functioning properly, and are not in a state of disrepair. Air assist gauges with pressure up readings indicate the plug exists further down stream from the transporter. Gauges with a low pressure reading indicate the plug exists upstream from the air assist, toward the transporter. The plugged area will therefore be between last high reading and first low reading air assist gauge.
3. Once the area of the plug has been established, tapping on convey tubing and listening for a tone change may further pinpoint plug location. Tapping on the pipe in the area plug may also dislodge the plugged pipe.
4. Increase transport air regulator setting in small increments until plug is voided or it has been determined that increasing air pressure will not unplug the system.

Disassembly is required at this point. All procedures prior to this step have been conducted with system in the "transport" mode.


**Note:** When the above procedure has been completed be sure to reduce regulator to its normal setting. Failure to do this could result in damage to the equipment and excessive wear.

5. Complete depressurization of system is critical prior to disassembly of any components on the system. Refer to the paragraph entitled "SYSTEM DEPRESSURIZATION PROCEDURE" for this procedure.
6. With system air supply turned off and depressurization of transporter completed, there still remains the possibility of air pressure being trapped in the conveying line between material plugs. Removal of the air assist assemblies just prior to and after conveying line coupling to be taken off is advised, greatly diminishing the possibility of a mishap.
7. Disassembly of convey tubing may now be implemented in the plug area. When plug has been cleared re-assembly of convey line should be done using installation guidelines.

**Note:** Once re-assembly is complete close emergency bleed-off valve, set transport regulator to its normal pressure setting and turn "Transporter Air Disable - Enable" selector switch to "Enable." Initiate a manual transport cycle to clear transporter and conveying line.

## SYSTEM DEPRESSURIZATION PROCEDURE

1. Turn "Transport Air Disable-Enable" selector switch near transporter to "Disable" and tag. If no selector switch is provided with your system turn the transport air regulator down to zero and tag.
2. Close the normally open "Pressure Switch Ball Valve" located between the transporter and pressure switch.
3. Slowly open the "Emergency Bleed-off Valve" located in the transporter top air supply line and tag. Some dusting may occur while transport air pressure is exhausted to atmosphere. When exhaust air flow stops and pressure gauge at the top of the transporter reads zero, the transporter should be depressurized.
4. Open the normally open "Pressure Switch Ball Valve." This will vacate the line of residual pressure and force any material away from the pressure switch.
5. Open the normally closed "Pressure Switch Ball Valve" for a short time (10 seconds) to back flush any material from the line. Close the valve.





**TROUBLE SHOOTING GUIDE**

<b>TROUBLE</b>	<b>CONDITION</b>	<b>POSSIBLE CAUSE</b>	<b>ACTION</b>
Load Cycle Can Not Be Initiated	Transporter Indicates Full	Level is High	Normal
		Transporter Level Switch Failure	Check and Adjust, Repair or Replace
	Receiving Bin Indicates Full	Level is High	Normal
		Receiving Bin Level Switch Failure	Check and Adjust, Repair or Replace
	Transporter Low Pressure Switch Indicates Not Low	Pressure is Not Low	Initiate Man. Transport
		(Pressure Trapped in Transporter)	To Clear System (See Transport Cycle Too Short)
		Transporter Low Pressure Switch Failure	Check and Adjust, Repair or Replace
	Convey Line Switch Indicates Not in Position & Sealed	Convey Line Switch Failure	Check and Adjust, Repair as Required (See Convey Line Switch Manual)
		Insufficient Air Supply to Switch	Check and Resolve
Load Cycle Time Excessive	Transporter Inlet Not Open	Material Build-Up on Valve Seat	Check and Remove as Required
		Insufficient Air Supply to Solenoid	Check and Resolve
		Transporter Inlet Solenoid Failure	Clean and Repair or Replace as Required
		Mechanical Binding of Inlet Valve or Actuator	Check and Adjust, Repair or Replace as Required
	Transporter Inlet Indicates Open but is Closed	Inlet Butterfly Shaft Bolts Sheared or Shaft Twisted	Repair and Check for Interference When Operated

**TROUBLE SHOOTING GUIDE**

<b>TROUBLE</b>	<b>CONDITION</b>	<b>POSSIBLE CAUSE</b>	<b>ACTION</b>
Load Cycle Time Excessive	Inlet is Open but Transporter Doesn't Fill	Material Supply Depleted	Check and Resolve
		Wet/Lumpy Material	Check and Resolve
		Aeration Failure	Check and Repair
	Transporter Overfills and Inlet Stays Open	Transporter Level Switch Failure	Manual Transport to Clear System; Adjust, Repair or Replace Level Switch as Required
Transport Cycle Can Not Be Initiated	Transporter Inlet Valve Indicates Not Closed	Material Build-Up or Foreign Object Lodged	Check and Remove as Required
		Insufficient Air Supply to Solenoid	Check and Resolve
		Transporter Inlet Solenoid Failure	Clean and Repair or Replace as Required
		Mechanical Binding of Inlet Valve or Actuator	Check and Adjust, Repair or Replace as Required
		Transporter Overfilled	Remove Manhole; Remove Enough Material to Allow Inlet to Close; Replace Manhole
		Transporter Closed Limit Switch Failure	Adjust, Repair or Replace as Required
	Receiving Bin Indicates Full	Level is High	Normal
		Receiving Bin Level Switch Failure	Check and Adjust, Repair or Replace

**TROUBLE SHOOTING GUIDE**

<b>TROUBLE</b>	<b>CONDITION</b>	<b>POSSIBLE CAUSE</b>	<b>ACTION</b>
Transport Cycle Can Not Be Initiated	Convey Line Switch Indicates Not in Position & Sealed	Convey Line Switch Failure	Check and Adjust, Repair as Required (See Convey Line Switch Manual)
		Insufficient Air Supply to Switch	Check and Resolve
Transport Cycle Too Short	Transport Cycle Turns on for 15 to 30 Seconds With Little or No Transport Pressure Increase	Transporter Inlet Indicates Closed but Shaft Bolts are Sheared or Shaft is Twisted and Valve is Partially Open	Check and Repair or Replace as required
		Transporter Inlet Indicates Closed but Limit is out of Adjustment and Valve is Partially Open	Check, Adjust, Repair or Replace as Required
		No Air Supply to System	Check and Resolve
		Transporter Pilot Regulator Out of Adjustment or Failure	Clean and Adjust, Repair or Replace as Required
		Transport Air on Solenoid Failure	Clean and Repair or Replace as Required
		Transporter Empty	Normal
	Transport Cycle Turns on for 15 to 30 Seconds or Longer But Ends Prior to Transporter Being Empty	Transporter Pilot Regulator Out of Adjustment or Failure	Clean and Adjust, Repair or Replace as Required
		Insufficient Air Supply to System	Check and Resolve
		Transport Air on Solenoid Failure	Clean and Repair or Replace as Required
		Transporter Top Air Regulator Failure	Clean and Repair or Replace as Required
		Transporter High Pressure Switch Failure	Check and Adjust, Repair or Replace

## TROUBLE SHOOTING GUIDE

TROUBLE	CONDITION	POSSIBLE CAUSE	ACTION
Transport Cycle Too Short	Material in Transporter Bridging or Rat Holing	Material Out of Design Specification	Check Material for Moisture-Mesh Size - Temp - Etc.; Contact <b>Nol-Tec Systems</b>
		Foreign Debris, Lumps or Chunks in Outlet	Insure Transporter is Depressurized; Remove Outlet; Clean Out Transporter; Replace Outlet

**Note:** When material is left in the transporter after a transport cycle, air pressure may be trapped in the transporter. Clear system via manual transport cycles or depressurize as stated in "SYSTEM DEPRESSURIZATION PROCEDURE" section of this manual.

Transport Cycle Too Long	Transport Pressure Lower Than Normal	Foreign Debris, Lumps or Chunks in Outlet	Insure Transporter is Depressurized; Remove Outlet; Clean Out Transporter; Replace Outlet
		Insufficient Air Supply to System	Check and Resolve
		Transporter Pilot Regulator Adjustment Low	Adjust as Required
		Transporter Top Air Regulator Failure	Clean and Repair or Replace as Required
	Transport Pressure Normal	Small System Air Leak	Check and Repair as Required
		One or More Air Assists Failed	Check and Repair or Replace as Required
		System Plugged	See CONVEYING LINE PLUG This Manual

## PRESSURE SWITCH SETTING PROCEDURE

### (DUAL SET POINT PRESSURE SWITCH)

Plant air must be available at the pressure switch for calibration. The procedure depicted utilizes a continuity tester or ohm meter and system POWER TURNED OFF. Refer to Air PRESSURE SWITCH detail Page 14 for component identification.

1. PS-1 low pressure switch adjustment. (PS-1 is identified on the pressure switch under the small access plate).
  - a. Connect a meter across the normally closed contact (terminals C and NC1) of PS-1, located under the large access plate of pressure switch (3).
  - b. Open ball valve (1) about half-way.
  - c. Close ball valve (4) until the pressure reading on gauge (2) is equal to 3 PSI.
  - d. Adjust PS-1 calibration screw, located under the small access plate of the pressure switch (3), so the normally closed contact transfers to the open position.
  - e. With meter still on the normally closed contact, open and close ball valve (4) and monitor gauge (2) to verify the setting. PS-1 should open as pressure increases to approximately 3 PSI and close when pressure drops near zero.
  - f. If necessary repeat steps c, d and e until the proper setting is reached.
2. PS-2 high pressure switch adjustment. (PS-2 is identified on the pressure switch under the small access plate).
  - a. Connect a meter across the normally open contact (terminals C and NO2) of PS-2, located under the large access plate of the pressure switch (3).
  - b. Open ball valve (1) about half-way.
  - c. Close ball valve (4) until the pressure reading gauge (2) is equal to the desired high pressure setting (8-15 PSI).
  - d. Adjust PS-2 calibration screw, located under the small access plate of the pressure switch (3), so the normally open contact transfers to the closed position.
  - e. With the meter still on the normally closed contact, open and close ball valve (4) and monitor gauge (2) to verify the setting.

- f. If necessary repeat steps c, d and e until the proper setting is reached.

***CAUTION:*** *When calibration is completed CLOSE VALVE (1) and OPEN VALVE (4) and TIE VALVE (4) IN THE OPEN POSITION. Failure to keep valve (4) in the open position will cause the system to function improperly and may cause damage to equipment.*